


Mixed Signal Oscilloscope

HMO series 3000

300-500MHz

User Manual

HAMEG[®]
Instruments
A Rohde & Schwarz Company





HAMEG®
Instruments
A Rohde & Schwarz Company

KONFORMITÄTSERKLÄRUNG DECLARATION OF CONFORMITY DECLARATION DE CONFORMITE DECLARACIÓN DE CONFORMIDAD

Hersteller / Manufacturer / Fabricant / Fabricante:
HAMEG Instruments GmbH · Industriestraße 6 · D-63533 Mainhausen

Die HAMEG Instruments GmbH bescheinigt die Konformität für das Produkt
The HAMEG Instruments GmbH herewith declares conformity of the product
HAMEG Instruments GmbH déclare la conformité du produit
HAMEG Instruments GmbH certifica la conformidad para el producto

Bezeichnung: Oszilloskop
Product name: Oscilloscope
Designation: Oscilloscope
Descripción: Osciloscopio

Typ / Type / Type / Tipo: HMO3002, HMO3004

mit / with / avec / con: HO730

Optionen / Options /
Options / Opciones: HO720, HO740

mit den folgenden Bestimmungen / with applicable regulations /
avec les directives suivantes / con las siguientes directivas:

EMV Richtlinien / EMC Directives / Directives CEM / Directivas IEM:
2004/108/EG;

Niederspannungsrichtlinie / Low-Voltage Equipment Directive / Directive des
équipements basse tension / Directiva de equipos de baja tensión:
2006/95/EG

Angewendete harmonisierte Normen / Harmonized standards applied /
Normes harmonisées utilisées / Normas armonizadas utilizadas:

Sicherheit / Safety / Sécurité / Seguridad:
DIN EN 61010-1; VDE 0411-1: 07/2011

Überspannungskategorie / Overvoltage category / Catégorie de surtension /
Categoría de sobretensión: II

Verschmutzungsgrad / Degree of pollution / Degré de pollution /
Nivel de polución: 2

Elektromagnetische Verträglichkeit / Electromagnetic compatibility /
Compatibilité électromagnétique / Compatibilidad electromagnética:

EMV Störaussendung / EMI Radiation / Emission CEM / emisión IEM:
DIN EN 61000-6-3: 09/2007 (IEC/CISPR22, Klasse / Class / Classe / classe B)
VDE 0839-6-3: 04/2007

Störfestigkeit / Immunity / Imunitee / inmunidad:
DIN EN 61000-6-2; VDE 0839-6-2: 03/2006

Oberschwingungsströme / Harmonic current emissions / Émissions de courant
harmonique / emisión de corrientes armónicas:
DIN EN 61000-3-2; VDE 0838-2: 06/2009

Spannungsschwankungen u. Flicker / Voltage fluctuations and flicker /
Fluctuations de tension et du flicker / fluctuaciones de tensión y flicker:
DIN EN 61000-3-3; VDE 0838-3: 03/2010

Datum / Date / Date / Fecha
08. 04. 2013

Unterschrift / Signature / Signatur / Signatura

Holger Asmussen
General Manager

General Information Regarding the CE Marking

HAMEG measuring instruments comply with regulations of the EMC Directive. HAMEG is basing the conformity assessment on prevailing generic and product standards. In cases with potentially different thresholds, HAMEG instruments apply more rigorous test conditions. Thresholds for business and commercial sectors as well as small business are applicable for interference emission (class 1B). As to the interference immunity, the standard thresholds for the industrial sector apply.

Measurement and data lines connected to the measuring instrument significantly affect compliance with specified thresholds. Depending on the respective application, utilized lines may differ. In regards to interference emission and immunity during measurements, it is critical that the following terms and conditions are observed:

1. Data Cables

It is imperative to only use properly shielded cables when connecting measuring instruments and interfaces to external devices (printers, computers, etc.). Unless the manual prescribes an even shorter maximum cable length, data cables (input/output, signal/control) may not exceed a length of 3 meters and may not be used outside of buildings. If the instrument interface includes multiple ports for interface cables, only one cable at a time may be connected. Generally, interconnections require double-shielded connecting cables. The double-shielded cable HZ72 (available at HAMEG) is well suitable as IEEE BUS cable.

2. Signal Cables

In general, measuring cables for the transmission of signals between measuring point and measuring instrument should be kept as short as possible. Unless an even shorter maximum cable length is prescribed, signal cables (input/output, signal/control) may not exceed a length of 3 meters and may not be used outside of buildings. All signal cables must be shielded (coaxial cable RG58/U). It is important to ensure proper ground connection. Signal generators require the use of double-shielded coaxial cables (RG223/U, RG214/U).

3. Impact on Measuring Instruments

If strong high-frequency electric and magnetic fields are present, it may occur despite diligent measurement setup that unwanted signal units are injected into the measuring instrument via connected measuring cables. This will not damage the HAMEG measuring instrument or put it out of operation. In some cases, these circumstances may cause the measuring value to slightly exceed specifications.

4. Interference Immunity in Oscilloscopes

4.1 Electromagnetic RF Field

If strong high-frequency electric and magnetic fields are present, field-related overlays in the measuring signal may become visible. Coupling of these fields may occur via power supply, measuring and control cables and/or via indirect radiation. This may affect both the measurement object and the oscilloscope.

Although the oscilloscope is shielded by the metal casing, direct radiation may occur through the monitor opening. Since the bandwidth of each amplifier stage is higher than the total bandwidth of the oscilloscope, overlaps with a frequency noticeably higher than the measuring bandwidth of -3dB may become visible.

4.2 Fast Transients / Discharging Static Electricity

Fast transients (Burst) and direct coupling via power supply or indirect coupling (capacitive) via measuring and control cables may trigger the event. Direct or indirect static discharge (ESD) may also affect the trigger. Since the triggering and signal display should also occur for signals with low signal amplitudes (<500µV), it is inevitable that these types of signals (> 1kV) activate the triggering and display simultaneously.


HAMEG Instruments GmbH

Content

General Information Regarding the CE Marking	2	6 Trigger System	26
Content	3	6.1 Trigger Modes Auto, Normal and Single	26
1 Installation and safety instructions	4	6.2 Trigger Sources	26
1.1 Symbols	4	6.3 Slope Trigger	27
1.2 Setting Up the Instrument	4	6.4 Puls Trigger	27
1.3 Safety	4	6.5 Logic Trigger	28
1.4 Intended Operation	5	6.6 Hold Off	29
1.5 Ambient Conditions	5	6.7 Video Trigger	29
1.6 Warranty and Repair	5	7 Signal Display	30
1.7 Maintenance	5	7.1 Display Settings	30
1.8 Measuring Category 0	6	7.2 Usage of the Virtual Screen	31
1.9 Mains Voltage	6	7.3 Signal Intensity Display and Persistence Function	31
1.10 Batteries and Rechargeable Batteries/Cells	6	7.4 XY Display	32
1.11 Product Disposal	7	8 Measurements	33
2 Introduction	8	8.1 Cursor Measurements	33
2.1 Front View	8	8.2 Automatic Measurements	34
2.2 Control Panel	8	9 Analysis	37
2.3 Screen	9	9.1 Mathematical Functions	37
2.4 Rear View	9	9.1.1 Quick Mathematics	37
2.5 Options	10	9.1.2 Formula Editor	37
2.6 General Operating Concept	10	9.2 Frequency Analysis (FFT)	39
2.7 Basic Settings and Integrated Help	11	9.3 Quick View	40
2.8 Bus Signal Source	12	9.4 PASS/FAIL Test Based on Masks	40
2.9 Updates to Instrument Firmware and Help	12	10 Documentation, Storage and Recall	42
2.10 Upgrade with Software Options	12	10.1 Instrument Settings	42
2.11 Self Alignment	13	10.2 References	43
2.12 Logic Probe Self Alignment	14	10.3 Curves	43
3 Quick Start Guide	14	10.4 Screenshots	44
3.1 Instrument Positioning and Start-Up	14	10.5 Formula Sets	45
3.2 Connecting a Probe and Capturing a Signal	14	10.6 FILE/PRINT Key Definition	45
3.3 Display of signal details	15	11 Mixed-Signal-Operation	46
3.4 Cursor Measurements	15	11.1 Logic Trigger for Digital Input	46
3.5 Automatic Measurements	16	11.2 Display Functions for the Logic Channels	46
3.6 Mathematical Settings	17	11.3 Cursor Measurements for Logic Channels	47
3.7 Storing Data	17	11.4 Automatic Measurements for Logic Channels	47
4 Vertical System	18	12 Serial BUS analysis	48
4.1 Coupling	18	12.1 The options HOO10, HOO11 and HOO12	48
4.2 Sensitivity, Y Positioning and Offset	19	12.2 Serial Bus Configuration	48
4.3 Bandwidth Limit and Signal Inversion	19	12.2.1 BUS Table	49
4.4 Probe Attenuation and Unit Selection (Volt/Ampere)	19	12.3 Parallel BUS	49
4.5 Threshold Setting	20	12.4 I ² C BUS	49
4.6 Naming a Channel	20	12.5 SPI / SSPI BUS	51
5 Horizontal System (time base)	21	12.6 UART/RS-232 BUS	53
5.1 Acquisition modes RUN and STOP	21	12.7 CAN BUS	55
5.2 Time Base Settings	21	12.8 LIN BUS	57
5.3 Acquisition modes	21	13 Remote control	58
5.4 Interlace Mode	24	13.1 Ethernet	58
5.5 ZOOM function	24	13.2 USB	59
5.6 Navigation function	25	13.3 RS-232 (option HO720)	59
5.7 Marker function	25	13.4 IEEE 488.2 / GPIB (Option HO740)	59
5.8 Search Function	25	14 Technical Data	60
		15 Appendix	63
		15.1 List of figures	63
		15.2 Glossary	64

1 Installation and safety instructions

1.1 Symbols



Symbol 1: Caution, general danger zone –
Refer to product documentation

Symbol 2: Risk of electric shock

Symbol 3: Ground

Symbol 4: Stop! – Risk harm to instrument

Symbol 5: PE terminal

Symbol 6: ON/OFF supply voltage

Symbol 7: Stand by display

Symbol 8: Ground terminal

1.2 Setting Up the Instrument

As shown in the illustrations, the handle can be pivoted into different positions:

A and B = Carrying position

C, D and E = Operating positions using different angles

F = Position to remove the handle.

G = Position using equipment feet, stacking position and to transport in the original packaging.

Removing/attaching the handle bar: The handle bar may be removed in position F by pulling it out further. To attach the handle bar, proceed in the reverse order.

Caution!

To change the position of the handle, the oscilloscope must be placed in a safe position so that it will not fall down (e.g. on a table). Then the handle knobs must be simultaneously pulled on both sides and pivoted in the direction of the desired position. If the handle knobs are not pulled out while pivoting them into the desired position, they may lock into the nearest locking position.

1.3 Safety

This instrument was built in compliance with VDE 0411 part 1, safety regulations for electrical measuring instruments, control units and laboratory equipment. It has been tested and shipped from the plant in safe condition. It is in compliance with the regulations of the European standard EN 61010-1 and the international standard IEC 1010-1. To maintain this condition and to ensure safe operation, the




Fig. 1.1: Various positions for HMO instruments

user must observe all instructions and warnings given in this operating manual. Casing, chassis and all measuring ports/terminals are connected to a protective earth conductor/safety ground of the mains. The instrument is designed in compliance with the regulations of protection class I.

The exposed metal parts have been tested against the main poles with 2200V_{DC} voltage.

For safety reasons, the instrument may only be connected to properly installed safety socket outlets. The power plug must be inserted before signal circuits may be connected. Separating the grounds is prohibited. If it is assumed that a safe operation is no longer possible, the instrument must be shut down and secured against any unintended operation.

Safe operation can no longer be assumed:

- If the instrument shows visible damage,
- If the instrument includes loose parts,
- If the instrument no longer functions properly,
- After an extended period of storage under unfavorable conditions (e.g. outdoors or in damp rooms),

- After rough handling during transport (e.g. packaging that does not meet the minimum requirements by post office, railway or forwarding agency).

1.4 Intended Operation

CAUTION! The measuring instrument is intended only for use by personnel familiar with the potential risks of measuring electrical quantities. For safety reasons, the oscilloscope may only be connected to properly installed safety socket outlets. Separating the grounds is prohibited. The power plug must be inserted before signal circuits may be connected. The oscilloscope is designed for use in the following sectors: Industrial sector, Home, Business or commercial sectors and Small businesses.

Use the measurement instrument only with original HAMEG measuring equipment, measuring cables and power cord. Before each measurement, measuring cables must be inspected for damage and replaced if necessary. Damaged or worn components can damage the instrument or cause injury.

To disconnect from the mains, the rubber connector on the back panel has to be unplugged.

The oscilloscope is designed for indoor use only. Before each measurement, you need to verify at a known source if the measurement instrument functions properly.

1.5 Ambient Conditions

Permissible operating temperatures during the operations range from +5 °C to +40 °C. During storage or transportation the temperature may be between –20 °C and +70 °C. In case of condensation during transportation or storage, the

Do not obstruct the ventilation holes!

instrument will require approximately two hours to dry and reach the appropriate temperature prior to operation. The oscilloscope is designed for use in a clean and dry indoor environment. Do not operate with high dust and humidity levels, if danger of explosion exists or with aggressive chemical agents. Any operating position may be used; however, adequate air circulation must be maintained. For continuous operation, a horizontal or inclined position (integrated stand) is preferable. The maximum operating altitude for the instrument is 2000 m above sea level.

Specifications with tolerance data apply after a warm up period of at least 30 minutes at a temperature of 23 °C (tolerance $\pm 2^\circ\text{C}$). Specifications without tolerance data are average values.

1.6 Warranty and Repair

HAMEG instruments are subject to strict quality controls. Prior to leaving the manufacturing site, each instrument undergoes a 10-hour burn-in test. This is followed by extensive functional quality testing to examine all operating

modes and to guarantee compliance with the specified technical data. The testing is performed with testing equipment that is calibrated to national standards. The statutory warranty provisions shall be governed by the laws of the country in which the HAMEG product was purchased. In case of any complaints, please contact your supplier.

Applicable only in EU countries:

To accelerate claims, customers in EU countries may also contact HAMEG directly for repairs. The HAMEG customer service is available for repair services even once the warranty period ends.

Return Material Authorization (RMA):

In any event, before returning an instrument, request a RMA number either via Internet (<http://www.hameg.com>) or by fax. If you need technical support or a suitable original packaging, please contact the HAMEG service department:

HAMEG Instruments GmbH
Service
Industriestr. 6
D-63533 Mainhausen
Telefon: +49 (0) 6182 800 500
Telefax: +49 (0) 6182 800 501
E-Mail: service@hameg.com

Any adjustments, replacements of parts, maintenance or repair may be carried out only by authorized HAMEG technical personnel. Only original parts may be used for replacing parts relevant to safety (e.g. power switches, power transformers, fuses). A safety test must always be performed after parts relevant to safety have been replaced (visual inspection, PE conductor test, insulation resistance measurement, leakage current measurement, functional test). This helps to ensure the continued safety of the product.



The product may only be opened by authorized and qualified personnel. Before any work is performed on the product or before the product is opened, it must be disconnected from the AC supply network. Otherwise, personnel will be exposed to the risk of an electric shock.

1.7 Maintenance

- Clean the outer case of the oscilloscope at regular intervals, using a soft, lint-free dust cloth.
- Before cleaning the instrument, please make sure that it has been switched off and disconnected from all power supplies.
- No instrument parts may be cleaned with alcohol or other cleaning agents!

The display may only be cleaned with water appropriate glass cleaner (not with alcohol or other cleaning agents). Follow this step by rubbing the display down with a dry,

clean and lint-free cloth. Do not allow cleaning fluid to enter the instrument. The use of other cleaning agents may damage the labeling or plastic and laquered surfaces.

1.8 Measuring Category 0

This oscilloscope is designed for measurements on circuits that are only indirectly connected to the mains or not connected at all. The instrument is in compliance with measuring category 0. Make sure the entry voltage does not exceed 200V (peak value), 150V_{RMS} at 1 MΩ input impedance and 5V_{RMS} at 50Ω input impedance.

The maximum value allowed for transient overvoltages is 200V (peak value). When performing measurements in circuits with transient overvoltages higher than category 0, make sure that no transient overvoltages higher than category 0 occur at the measurement input. To ensure compliance, it is necessary to only use probes that have been manufactured and tested in accordance with DIN EN 61010-031. When performing measurements in category II, III or IV circuits, it is mandatory to insert a probe that reduces the voltage so that no transient overvoltages higher than category 0 will be applied to the instrument. Direct measurements (without galvanic isolation) to category II, III or IV circuits are prohibited! The measuring circuits are considered not connected to the mains if an isolation transformer in compliance with safety class II is used. It is also possible to perform measurements on the mains if appropriate transformers (e.g. current connectors) are used that are in compliance with safety class II. The measurement category (for which the manufacturer specified the required transformer) must be observed.

Measurement Categories

The measurement categories refer to transients from the power system. Transients are short, very fast (steep) current and voltage variations which may occur periodically and non-periodically. The level of potential transients increases as the distance to the source of the low voltage installation decreases.

Measurement CAT IV: Measurements at the source of the low voltage installations (e.g. meters)

Measurement CAT III: Measurements in building installations (e.g. power distribution installations, power switches, firmly installed sockets, firmly installed engines etc.).

Measurement CAT II: Measurements on circuits electronically directly connected to the mains (e.g. household appliances, power tools, etc.)

Measurement category 0 (previously Measurement CAT I): Electronic devices and fused circuits in devices.

1.9 Mains Voltage

The instrument applies 50 and 60 Hz mains voltages ranging from 100 V to 240 V (tolerance ±10%). Mains voltage switching is therefore not required. The input line fuse is accessible externally. Power socket and fuse holder form

a single unit. You need to first disconnect the power cord from the connector before you can safely replace the fuse (as long as the fuse holder is undamaged). Next the fuse holder must be pried out using a screwdriver. The starting point is a slot next to the contacts. Then the fuse can be forced out of its mounting and must be replaced by an identical fuse (please find information about the fuse type below). The fuse holder will be inserted against the spring pressure until it locks into place. The use of mended fuses or to short circuit the fuse holder is prohibited. Resulting damages are not covered by the warranty.

Fuse type: IEC 60127 - T2.5H 250V, size 5 x 20 mm

1.10 Batteries and Rechargeable Batteries/Cells

If the information regarding batteries and rechargeable batteries/cells is not observed either at all or to the extent necessary, product users may be exposed to the risk of explosions, fire and/or serious personal injury, and, in some cases, death. Batteries and rechargeable batteries with alkaline electrolytes (e.g. lithium cells) must be handled in accordance with the EN 62133 standard.

1. Cells must not be disassembled, opened or crushed.
2. Cells and batteries may not be exposed to heat or fire. Storage in direct sunlight must be avoided. Keep cells and batteries clean and dry. Clean soiled connectors using a dry, clean clothes.
3. Cells or batteries must not be short-circuited. Cells or batteries must not be stored in a box or in a drawer where they can short-circuit each other, or where they can be short-circuited by other conductive materials. Cells and batteries must not be removed from their original packaging until they are ready to be used.
4. Keep cells and batteries out of reach of children. Seek medical assistance immediately if a cell or battery was swallowed.
5. Cells and batteries must not be exposed to any mechanical shocks that are stronger than permitted.
6. If a cell develops a leak, the fluid must not be allowed to come into contact with the skin or eyes. If contact occurs, wash the affected area with plenty of water and seek medical assistance.
7. Improperly replacing or charging cells or batteries that contain alkaline electrolytes (e.g. lithium cells) can cause explosions. Replace cells or batteries only with the matching type in order to ensure the safety of the product.
8. Cells and batteries must be recycled and kept separate from residual waste. Cells and batteries must be recycled and kept separate from residual waste. Recharge-

able batteries and normal batteries that contain lead, mercury or cadmium are hazardous waste. Observe the national regulations regarding waste disposal and recycling.

1.11 Product Disposal



Fig. 1.2:
Product labeling in accordance with EN 50419

The German Electrical and Electronic Equipment Act implements the following EC directives:

- 2002/96/EC (WEEE) for electrical and electronic equipment waste and
- 2002/95/EC to restrict the use of certain hazardous substances in electronic equipment (RoHS directive).

Once its lifetime has ended, this product should be disposed of separately from your household waste. The disposal at municipal collection sites for electronic equipment is also not permitted. As mandated for all manufacturers by the German Electrical and Electronic Equipment Act (ElektroG), HAMEG assumes full responsibility for the ecological disposal or the recycling at the end-of-life of their products.

Please contact your local service partner to dispose of the product.

2 Introduction

2.1 Front View

On the instrument frontside you can find the power key [1], in order to switch on the instrument or to enter stand-by mode. If the instrument is in stand-by mode, this key lights up red. If the instrument is switched off using the

Use the connectors [52] [53] for the active logic probes exclusively for the logic probes of type H03508. Connecting other types may demolish the inputs.

main power switch on the backside, the red light will also switch off (this will take some seconds). Furthermore you find on the front panel the the control panel [2], [A], [B], [C], [D], the BNC connectors of the analog inputs [45] to [48], the probe adjustment output [51], the BUS signal source [50], the connectors [52] [53] for the optional logic probes HO3508, a USB port for USB sticks [54], the TFT screen [55] and the LED [49] for showing activity on the remote interface. The two channel instruments includes an AUX socket for external trigger on the right side.

2.2 Control Panel

The controls in the front panel allow access to all basic functions while advanced settings are easily accessible through the menu structure and gray soft menu keys. The power button [1] is clearly set apart by its design. The most significant controls feature colored LEDs, indicating




Fig. 2.2:
Section A of
the control
panel

the current setting. The control panel is divided into four sections.

Section A

This section includes the CURSOR/MENU, ANALYZE and GENERAL sections. The CURSOR/MENU section includes cursor functions [6] [8], universal knob [4], Intens/Persist control switch [7] and the option to select the virtual screen [5].

If you press the AUTOSSET button [15] longer then 3 seconds, the HMO will be reset to its default settings!

The ANALYZE section allows users to directly access the FFT displays [9], the Quick View [10] display (all important parameters of the actual signal display), the PASS/FAIL mask test, and the AUTOMEASURE settings [11].

The General section includes the Save/Recall [12] key. With this option, you can control the settings to load and save instrument settings, reference signals, signals, screen dis-




Fig. 2.1: Frontview of the HMO3004

plays and sets of formulas. Additional keys enable the user to access general settings [13] such as language, DISPLAY [14], AUTO-SET [15] as well as integrated HELP [16] and FILE/PRINT [17]. Depending on how it is programmed, FILE/PRINT enables you to directly save instrument settings, signals and screen displays or print on a postscript printer.

Section B:

The VERTICAL section features all controls for analog channels, such as the position control knob [18], the XZ mode select key [19], the vertical gain adjustment knob [20], the advanced menu options key [21], the channel select keys [22] to [25] and the optional logic probes HO3508 [24] [25]. You can also access the MATH key and the reference signal settings key here [27].

Section C:

The TRIGGER section includes all options to set the trigger level [28], to switch between AUTO and NORMAL mode [29], to set the trigger type [31], the source [32], the single sweep, to switch the trigger slope and to set the trigger signal filters. Additionally, you can find status indicators, and you can see if a signal fulfills the trigger conditions [30] and which slope is used [34].

Section D:

In the HORIZONTAL section, users can shift the trigger position horizontally or set and navigate markers manually, either step-by-step with the keys [37] [38] [39] or alternatively by using the smaller one of the knobs [41]. In the menu, you can also set search criteria for events. The illuminated key [39] allows the selection of the RUN and STOP mode. When the STOP mode is selected, the key will light up in red. [40] activates the zoom option, [43] adjusts the time base speed and [42] enables access to the time base menus.

To the left of the control panel, you also find the soft menu keys [2] to control the menu options.




Fig. 2.3: Section B, C and D of the control panel

2.3 Screen

The HMO series is equipped with a 6.5" (16.51 cm) TFT color monitor with LED backlight and VGA resolution (640x480 pixels). In the default setting (no menus shown), the screen includes 12 scale divisions on the time axis.




Fig. 2.4: Screen view

If menus are shown, this will be reduced to 10 divisions. Small arrows [1] on the left of the display indicate the reference potentials of the channels. The line above the graticule includes status and settings information such as time base, trigger delay and other trigger conditions, the current sampling rate and the acquisition mode [2]. The short menu to the right of the graticule contains the most important settings of the currently active channel. You may select these settings using the soft menu keys [3]. Measurement results for automated measurements and cursors, settings for the activated vertical channels, reference signals and mathematically derived curves are shown in the lower section of the screen [4]. Within the graticule, signals of the selected channels are displayed. By default, 8 scale divisions are shown. This can be extended virtually to 20 divisions which can be displayed using the Scroll/Bar [5] key.

2.4 Rear View




Fig. 2.5: Rear panel HMO3004 series

The rear panel of the HMO series features the connector for the power supply [1], the receptacle for the interface modules [2] (Ethernet/USB, USB/RS-232, IEEE-488), the

standard DVI-D connector [3] to connect external digital monitors and projectors, the BNC connector for the AUX-OUT [4] and for the external trigger [5]. The 2-channel instrument does not include the BNC connector for the external trigger [5]. For this model, it is located on the front panel.

2.4.1 DVI Connector

The rear panel of the oscilloscope includes a standard DVI-D connector to connect external monitors and projectors. The DVI-D connector can only send digital signals. This means it is impossible to connect monitors or beamers via their analog inputs. The HMO series yields a DVI signal with VGA resolution (640x480). This design enables connectivity with all standard TFT monitors. Modern flat screens extrapolate the signal, allowing users to see a full screen.

Beamers can also be connected to the HMO. Ideal beamers in this case are those designed to be connected to computers/ notebooks as these are also able to process a 640 x 480 pixel resolution.

2.5 Options

The HMO series offers several options which allow the user to expand the range of application considerably. The following interface modules are available and may be installed by the customer in the rear receptacle (by default equipped with a Ethernet/USB HO730 dual interface):

- HO740 (IEEE-488, GPIB, galvanically isolated)
- HO720 (combination of RS-232 and USB)

All HMO series instruments are prepared for mixed-signal operation and include the appropriate connectors on the front panel. Each of these connectors can be connected to an 8-channel logic probe HO3508, allowing a maximum of 16 digital logic channels. Other available options are the passive 500MHz Slimline 10:1 probe of type HZ355 (included in delivery with HMO3052 und HMO3054), passive 1000:1 probes with up to 4000V of type HZO20, active 10:1 probes with <1pF input capacity of type HZO30, active difference amplifier probes HZ100, HZ109 and HZ115 with up to 1000VRMS and 40MHz, active high speed differential probes HZO40 and HZO41 with 200 or 800MHz bandwidth, the current probes HZO50 and HZO51 with up to 100kHz bandwidth and up to 1000A, the 19" rack mount set HZ46 and the HZ99 bag for transportation and protection of the instruments. The options HOO10/11/12 allow the analysis of serial buses. For more information, please refer to chapter 2.10. Additionally, you are able to upgrade the bandwidth of the instrument by an optional license key at any time (HOO352, HOO354, HOO452, HOO454).

2.6 General Operating Concept

Our oscilloscopes are renowned for their ease of use. The user-friendly operation is based on a few key principals, recurring with various settings and functions.

- Keys that do not open a soft menu (e.g. SCROLL BAR) activate a specific function; pressing this key a second time will deactivate this function.
- Keys that call a specific function (e.g. FFT) which in turn enable or require additional settings, activate a function when pressed once; pressing this key a second time will activate the soft menu for the settings while pressing it a third time deactivates the function.
- Keys that open a soft menu when pressed once will close the soft menu when pressed a second time.
- Depending on the requirements, the universal knob is designed to either select a numeric value or to navigate through submenus.
- The MENU OFF key below the soft menu keys closes the current menu or switches to the next higher level.
- Pressing the appropriate key will activate a deactivated channel. If a channel was already activated, selecting another channel will change operation to the channel whose key was pressed (its LED lights up). Pressing an illuminated channel key for a channel that is already displayed and selected will deactivate this channel and, depending on availability, activate the next channel in the sequence CH1 >CH2 >CH3 >CH4.
- If cursor measurements are activated, the COARSE/FINE key will select the cursor with the activated universal knob in the CURSOR/MENU section. This key is used to select or confirm input in all menus for alphanumerical input and for the file manager.

The soft menus include some frequently used navigation elements as described below.

Fig. 2.6 illustrates the choice between two selection elements. To select from the three upper elements, press the corresponding soft menu key with the element marked in blue. A second option is shown in the two lower menu entries. By pressing the corresponding key, you may toggle between the options. The active selection is also marked in blue.

Fig. 2.7 illustrates how to use these menus for functions that have to be activated or require to have values set. You




Fig. 2.6: Selection of basic soft menu elements



Fig. 2.7: Basic soft menu elements for settings and navigation

may toggle between OFF and the set value. The round arrow on the bottom right of the menu window indicates that the value is to be set by means of the universal knob in the CURSOR/MENU section. A small triangle on the bottom right of a menu item indicates a lower menu level. You can navigate additional pages on the same level by using the last menu item. It includes the number of menu pages on this level as well as the current page number. You can advance to the next page by pressing the appropriate soft menu key. Once the last page was listed, the display will loop back to the the first page.

2.7 Basic Settings and Integrated Help

You can access important basic settings such as language for user interface and help, general settings and interface settings in the menu that opens when you press the SETUP key in the GENERAL section of the control panel. On the first page of the menu for the basic settings you can select the language for user interface and help.

Pressing the soft menu key MISC opens a menu to select the following settings:

- MENU OFF (selection of manual or automatic with time limit of 4-30 seconds to hide soft menus)
- TIME REFERENCE (position to reference the trigger time from -5 scale divisions to +5 scale divisions where 0 is the middle and default)
- DATE & TIME (menu to set date and time)
- SOUND (menu to set any combination of sound - as beep during setup, in the event of an error and for triggers)
- DEVICE NAME (menu to set a name with a maximum of 19 characters included with printouts)
- LOGO IN SCREENSHOT (select whether to include HAMEG logo in the upper right of the printout or not)
- AUTOSET KEY (activate or block functionality of the AUTOSET key)

Depending on the installed interface (USB and RS-232 by default), the menu item INTERFACE activates the menus to perform the interface configuration.

The menu item PRINTER includes settings for POSTSCRIPT and PCL compatible printers. When pushing this




Fig. 2.8: Menu for basic settings

soft menu key, a submenu opens allowing the user to select the paper format and color mode. Using the assigned soft menu key, the top menu item PAPER FORMAT allows you to choose from A4, A5, B5, B6, Executive, Letter and Legal in either portrait or landscape format. Use the universal knob in the CURSOR/MENU section to select the appropriate format.

Following the same setup procedure, the menu item COLOR MODE allows you to choose between Grayscale, Color and Inverted. The Grayscale mode converts the color image to a grayscale image which can be printed on a black-and-white postscript printer. The Color mode prints the image in color as shown on the screen (black background). The INVERTED mode prints the color image with a white background on a color printer thus saving toner and ink.

When using the INVERTED mode, you should set the intensity of the signals to about 70% to allow a high contrast print.

The menu item DEVICE INFORMATION opens a window with detailed information on hardware and software of the measuring instrument.




Fig. 2.9: Updating menu and information window

The second page includes the menu for the instruments and help update (for more information, please refer to the following chapter) and the PROBE COMP and BUS SIGNAL SOURCE. Pushing this soft menu key will open a submenu for the PROBE ADJUST output and the BUS signal source. For a detailed description of the settings, please read chapter 2.8.

The integrated help can be activated by pushing the HELP key in the GENERAL section of the control panel. This opens a window with explanatory text, and the HELP key is illuminated. The text in the help window is dynamically updated with descriptions of the corresponding setting or function. If you no longer require help, push the HELP key to close the HELP option. This will turn the LED indicator for the key off and the text window for the help will close.

2.8 Bus Signal Source

To the left of channel 1, the HMO series features four contacts generating the following signals (depending on the respective settings):

- Square wave signal for probe compensation (default setting), frequency 1 kHz or 1 MHz
- SPI signal, data rates 100 kBit/s, 250 kBit/s or 1 MBit/s
- I²C signal, data rates 100 kBit/s, 400 kBit/s or 1 MBit/s
- UART signal, data rates 9600 Bit/s, 115,2 kBit/s and 1 MBit/s
- Parallel stochastic bit pattern, frequency 1 kHz or 1 MHz
- Parallel counter signal, frequency 1 kHz or 1 MHz

The contact at the upper left is always ground and the signal levels are about 1 V. The table below shows how the four outputs S1, S2, S3 and $\overline{S4}$ are used, depending on the signal.

Signal	S1	S2	S3	$\overline{S4}$
SQUARE WAVE	no signal	no signal	no signal	Square wave
SPI	Chip Select Low aktiv	clock, rising edge	data, high active	no signal
I ² C	no signal	Clock SCL	data SDA	no signal
UART	no signal	no signal	data	no signal
Pattern	Bit 0	Bit 1	Bit 2	Bit 3
Counter	Bit 0	Bit 1	Bit 2	Bit 3

To access the setup menu for the BUS signal source, press the SETUP key in the GENERAL section of the control panel, select page 2|2 and press the soft menu key PROBE COMP. Now you may select the desired operating mode for the BUS signal source. For each mode of operation, an image with the corresponding pattern of signals on the contacts is displayed. By pressing a soft menu key, you can open a submenu with the speed setting of the selected operating mode.

The following options are available for the SQUARE WAVE signal for probe compensation: 1 kHz for the low frequency compensation, 1 MHz for the high frequency compensation or AUTOMATIC (default setting). In the Automatic mode, the output will provide 1 kHz at time bases from 100 μ s and provide 1 MHz at smaller time bases. These different signals allow users to become familiar with and verify the settings for the parallel and optional serial BUS analysis.

2.9 Updates to Instrument Firmware and Help

The HMO series is constantly being advanced. You can download the current firmware at www.hameg.com. Firmware and help are packed in one ZIP file. Depending on the required extent of the update, the ZIP file might include either all updates or simply the instrument firmware, for instance. After downloading the ZIP file, unpack the data to the base directory of a USB stick. Then connect the USB stick with the USB port of the oscilloscope and press the SETUP key in the GENERAL section of the control panel. The menu item UPDATE can be found on page 2|2. Selecting this menu item opens a window displaying




Fig. 2.10: Menu and information window for help updates

version number, date and build information of the currently installed firmware. Instrument firmware or help can be updated at this point.

Pressing the soft menu key to update the instrument firmware will result in a search for the corresponding file on the USB stick. The information for the new firmware to be installed will then be displayed on the stick below the row labeled NEW:. The version number will be displayed in red in case the existing firmware on the instrument is identical to the latest version; otherwise the version number will be shown in green. Only if this is the case, press the soft menu EXECUTE to start the update. Choose the HELP menu item in the Update menu if you intend to update the help or add a new language for help.

The information window will now display all installed languages, the date and relevant information about the languages available on the stick. The soft menu allows you to add, remove or update languages. Please note the date format (YYYY-MM-DD) in compliance with multilingual help ISO 8601 standards.

2.10 Upgrade with Software Options

The HMO series may be upgraded with options made available by entering a licence key. At this time, options HOO10/HOO11/HOO12 and und HOO352/HOO354/HOO452/HOO454 are available. The option HOO10 allows




Fig. 2.11: „UPGRADE“ menu.

triggering and decoding of up to two serial buses I2C, SPI, UART/RS-232 on digital channels (with option HO3508) and on analog channels. HOO11 allows these features only on analog channels and with only one BUS. HOO12 allows triggering and decoding of up to two serial buses CAN and LIN both on analog and digital channels. The options HOO352, HOO354, HOO452 and HOO454 allows you to upgrade the bandwidth via license key.




Fig. 2.12: Manual licence key input.

Typically, you will receive the licence key by email as a file attachment (name: SERIAL NUMBER.hlk). The attached ASCII file may be opened with an editor. This allows you to read the actual key in plain text. You can choose between two methods to enable the desired option with this key: an automated reading or manual input.

The automated reading via USB stick is the fastest and easiest method. Store the licence file on a USB stick and then install it to the instrument using the FRONT USB port. Press the SETUP key in the GENERAL section of the HMO control panel to open the SETUP menu. You will find the LICENCES menu on page 2|2. The following menu appears:

Press the soft menu key READ KEYS from licence file to open the file manager. Select the required licence file with the universal knob in the CURSOR/MENU section and then use the soft menu key LOAD to load it. This will load the licence key, making the option instantly available by restarting the instrument.

Alternatively, you can enter the licence key manually. Select the menu UPGRADE and press the soft menu key INPUT KEY manually. This will open an input window. Use the universal knob in the CURSOR/MENU section and the ENTER key to enter the licence key manually. After entering the complete key, press the soft menu key ACCEPT to confirm the entry. The option will be activated after restarting the instrument.

2.11 Self Alignment

The HMO series features an integrated self alignment procedure to achieve the highest possible accuracy. During the standard self alignment the HMO adjusts vertical

accuracy, offset, time base and several trigger settings and saves the identified correction data internally.

The instrument must have reached the required operating temperature (switched on for at least 20 minutes) and all inputs must be unused, in other words all cables and probes must be removed from the inputs.

To start the self alignment in the SETUP menu, go to page 2|2, press the soft menu key SELF ALIGNMENT and press the START key. The procedure will run for about 5-10 minutes. Each step and its corresponding progress will be shown in a bar display. After completion of a successful self alignment, you will see a similar message as shown in Fig 2.13.




Fig. 2.13: Successful self alignment

Press the soft menu key EXIT to close the Self Alignment menu. Abort the self alignment by pressing the soft menu key ABORT. Aborting the self alignment procedure should be the exception, e.g. if you failed to remove all probes from the inputs. Once the procedure has been aborted, it is important to carry out a complete self alignment.

If an error occurs during the self alignment although it has been carried out as described, please send the exported .log file (see Self Alignment menu) to support@hameg.com. You can save the .log file to a USB stick.




Fig. 2.14: Logic probe self alignment (refer to page 14)

2.12 Logic Probe Self Alignment

The self alignment for the logic probe primarily aligns the switching levels.

To start the self alignment for the logic probe, it is necessary that the logic probe type HO3508 is connected to the HMO. It is imperative that the bit connectors are not connected. To start the process, select the menu item LOGIC PROBE SELF ALIGNMENT. The process is similar to the basic instrument alignment but it only takes a few seconds. (please refer to Fig. 2.14 on page 13).

3 Quick Start Guide

The following chapter is an introduction to the most important HMO oscilloscope features and settings allowing you to use the instrument promptly. The integrated calibrator signal output is used as the signal source which means that the first steps will not require any additional instruments.

3.1 Instrument Positioning and Start-Up

To optimally set up the instrument, position the handle so that the display will be inclined slightly upwards (please see chapter 1.1 on how to position the handle). Plug the power cord into the rear panel connector. To start the instrument, press the red On/Off key [1] on the front panel. The display appears after a few seconds, and the oscilloscope is ready for operation. Press the AUTOSET key [15] for at least 3 seconds. This will reset the most important oscilloscope settings to their default settings.




Fig. 3.1: Section A of the control panel

3.2 Connecting a Probe and Capturing a Signal

Make sure to align the passive probes prior to their first use. For more information, please refer to the probe manual. Place the probe in the appropriate position on the ADJ. output. The tip will be accepted by the hole of the right output and the ground connection connects with the left output, as shown in Fig. 4.3 in chapter 4.

Take one of the provided probes HZ350 resp. HZ355 and remove the protective cap from the tip. Apply the probe




Fig. 3.2: Screen display after connection of the probe




Fig. 3.3: Screen display after changing to DC coupling

compensation box to the BNC connector for channel 1 and turn the black knob to the right until it latches into place.




Fig. 3.4: Screen display after Autosetup

On the right hand side of the screen, you will see the short menu for channel 1. Press the soft menu key to the right of each menu item to select frequently used settings. Press the top soft menu key to change the input coupling to DC.

IMPORTANT: Active settings are marked in blue.

Briefly press the AUTOSSET key once [15]. After a few seconds, the oscilloscope will have automatically selected the sensitivity, time base and trigger settings. A square wave signal will now be shown.

3.3 Display of signal details

With the time base knob [43] you can change the displayed time window. Turning it CCW increases the time base. The memory depth of 4 MB per channel allows you to capture wide time windows with high resolution. Continue to turn




Fig. 3.5: Section D of the control panel with zoom key

the knob CCW until you can read "TB:5ms" in the upper left corner of the screen. Press the ZOOM key [40].

You will see the following two window display: The upper section of the window displays the entire captured signal whereas the lower section shows an enlarged section. Use the time base knob to select the zoom factor. The small knob allows you to determine the horizontal position of the section.




Fig. 3.6: Zoom function

Press the ZOOM key [40] again to deactivate the zoom mode.

3.4 Cursor Measurements

After displaying and reviewing the signal, the next step will introduce cursor measurements of the signal. Again, briefly press the AUTOSSET key once followed by the CURSOR/MEASURE key. You can now select the desired type of measurement cursor from the menu. Press the top soft menu key MEASURE TYPE to open the appropriate selection menu. You can specify your selection with the universal knob in the CURSOR/MENU section of the control panel. Turn the knob CCW until the entry "V marker" is marked in blue. Press the MENU OFF key to close the menu or wait until it automatically closes after a few seconds. Now two cursors will be shown along the signal as well as the measurement results on the bottom of the




Fig. 3.7: Cursor measurements

display. Press the universal knob to select the active cursor and turn the universal knob to position the cursor.

The cursor measurement results will be shown on the bottom of the display. In this example with the entry “V marker”, the display includes the voltage at both cursor positions, their difference, and the time difference between the cursor positions. To switch off the cursor, press the CURSOR MEASURE key again.

3.5 Automatic Measurements

In addition to cursor measurements, automatic measurements can display the most important signal parameters.

Your HMO offers two options:

- Display definition of 6 parameters from varying sources,
- Quick display of all important parameters of one source by use of the QUICK VIEW feature.

Please change the time base to 100µs per scale division and press the QUICKVIEW **[10]** key. You will see the following display:




Fig. 3.8: Quickview parameter measurement

The following list features the most important parameters of a signal:

- positive and negative peak voltages,
- rise and fall times,
- mean voltage.

10 additional parameters are shown below the grid:

- RMS,
- frequency,
- amplitude,
- pos. pulse width,
- pos. duty cycle,
- peak-peak voltage,
- period,
- number of rising edges,
- neg. pulse width,
- neg. duty cycle.

With just one key, you can view all available parameters simultaneously that characterize the signal. This feature always applies to the currently active display channel. You may also display parameters for several signals. For this option, press the QUICKVIEW **[10]** key twice to deactivate

this mode, press the CH2 key **[23]** to activate CH2 and press the AUTO MEASURE **[11]** key to open the menu as displayed below.




Fig. 3.9: AutoMeasure menu

Pressing the MEAS. PLACE soft key will display a list. Use the universal knob in the CURSOR/MENU section to choose the appropriate measurement place. The parameters will be displayed at the bottom of the screen. This




Fig. 3.10: Selection of parameter

menu allows you to define the parameters. Use the appropriate menu key to select the desired field and use the universal knob **[4]** in the Cursor menu section to complete the selection. This procedure is used in all soft menus where selections are available. In this example, press the menu key TYPE and use the universal knob to select the rise time as parameter.

Select Measurement Place 1, select MEAN as measurement type and CH1 as source. Press the MEAS. PLACE soft menu key on top to select the second measurement place. Define the measurement place as before as RMS value with the voltage of CH2. Page 2 of this menu allows you to activate complete statistics for the selected channels, including the current measurement value, the smallest, the largest and the mean value, the standard deviation and the number of values used for the statistics. Once the menu is closed, parameters can be easily identified by the




Fig. 3.11: Measuring the parameters of two sources

colors of the respective source signal (in this instance, yellow for channel 1 and blue for channel 2).

3.6 Mathematical Settings

In addition to cursor and automatic measurements, your HMO can also apply mathematical operations to the signals. Pressing the MATH [26] key and the QM resp. the MENU key in the VERTICAL section opens a quick math menu (QM) enabling you to apply addition, subtraction, multiplication or division to two analog channels. This also displays the mathematical graph. The top soft menu key allows you to select the first operand. With the key below, you can select the operator (in quick mathematics you can choose between addition, subtraction, multiplication or division). The soft menu key below that allows you to select the second operand. Only activated and displayed channels are available for the operands. Press the bottom soft menu key FORMULARY. This opens the formula editor to select and define 5 potential sets of formulas with up to 5 mathematical functions each.




Fig. 3.12: Formula editor

To change the settings, use the soft menu keys and the universal knob [4]. Here you can define and store the most frequently used formulas. After selecting the desired formula and pressing the soft menu key EDIT, you can edit individual formula functions. Once a mathematical function has been defined and activated by pressing the

soft menu key VISIBLE (ON), the short menu for the mathematical functions will display this function. The graph will be marked in the short menu by a red dot. The sources selected in the function must be activated so that the mathematical graph can be calculated and the result signals can be displayed.

3.7 Storing Data

Your HMO is able to store 5 different types of data:

- Instrument settings
- Reference signals
- Signals (up to 24,000 points)
- Screen displays
- Sets of formulas

Out of these data types, signals and screen displays can only be stored on a USB stick. All other data types can be stored on a USB stick or internally in the instrument to non-volatile storage media. To store data you have to define the data type and the destination to be used for storing. First attach a USB stick to the front USB connector of your oscilloscope. Press the SAVE/RECALL [12] key to open the respective menu.




Fig. 3.13: Save/Recall menu

Select the type of data you wish to store by pressing the respective soft menu key (in this example SCREENSHOTS). This will open the settings menu.




Fig. 3.14: SCREENSHOTS menu

In the top menu make sure that Storage Front is selected. Press the soft menu key to open the menu where you can select these settings. It is important to connect a USB stick with the front USB connector of your oscilloscope which must be recognized by your instrument. Pressing the soft menu key SAVE allows you to save a screenshot using the default file name (the current file name is displayed in the menu item FILE NAME). You can also select a name for the target file with up to 8 characters. Select the menu item FILE NAME and use the universal knob to enter the name (in this example "TRC").




Fig. 3.15: File naming

Press the soft menu key ACCEPT. The oscilloscope accepts the name and returns to the settings menu. Here you can store the current image by pressing the soft menu key SAVE. Alternatively, you can move up one level in the menu by using the OFF key on the bottom and select the menu item FILE/PRINT. In the following menu press the soft menu key SCREENSHOTS. This will assign the function Screenshot to the FILE/PRINT [17] key with the selected settings. This enables you to generate a screenshot on your USB stick by pressing the FILE/PRINT key at any given time using any menu.

4 Vertical System




Fig. 4.1: Control panel for the vertical system

You can select vertical settings using knobs for the vertical position and the sensitivity. You may also use a menu that is permanently displayed as well as an advanced menu.

You can select for which channel you want the settings to be activated by pressing the respective channel key. Once a channel has been activated, the key will be marked by a colored LED light in the corresponding channel color.

Additionally, the screen display will include a frame around the activated channel with a frame and a color brighter than that of deactivated channels. The corresponding short menu is always visible and you can push the MENU [21] key to activate the advanced menu.




Fig. 4.2: Short menu for vertical settings

4.1 Coupling

When coupling analog inputs, you need to first select the input impedance (1 MΩ or 50 Ω)

Do not connect the 50Ω inputs to effective voltage higher than 5 volts!

The 50Ω inputs should only be selected if the signal source is 50Ω, such as a generator with a 50Ω output impedance and if the oscilloscope displays the line termination at the ending point of the signal path. In all other cases, select coupling with 1 MΩ input resistance. Next, the user determines if DC coupling or AC coupling is to be used. With CD coupling, the DC voltage of the signal will be displayed. With AC coupling, an input filter of 2 Hz suppresses the display of DC voltage. Signals of up to 200V

RMS voltage may be connected directly to 1 M Ω inputs. Higher voltages can be measured with external probes (up to 40 kV peak voltage). This should only be used with DC coupling. For all general applications, the probes HZ350 (10:1, 10 M Ω || 12 pF, max. 400 V_p) supplied with the instrument will be used. These are specified for the 1 M Ω inputs and feature a 10 M Ω impedance and partial automatic recognition.

Make sure to align the passive probes prior to their first use. For more information, please refer to the probe details.

The PROBE ADJUST output of the HMO oscilloscope is only suitable for 1:1 and 1:10 probes. 100:1 or 1000:1 probes require special generators! Use the shortest possible ground connection to the PROBE ADJUST output as shown in Fig. 4.3.

You can set the coupling using the short menu. Simply press the respective soft menu key to set the coupling and the graphic inversion of the input channel. The menu applies to the corresponding active channel. The illuminated channel key indicates which channel is active. The channel name of the active channel is shown at the top of the short menu. You can switch between channels by pressing the respective channel key.




Fig. 4.3: Correct connection of the probe to the probe adjust output

4.2 Sensitivity, Y Positioning and Offset

You can select the sensitivity of the analog inputs by using the knob in the VERTICAL section of the control panel in 1-2-5 steps of 1 mV/div to 5 V/div for the 1 M Ω and 50 Ω coupling. The knob is associated with the active channel (push the respective channel key to activate the desired channel). Pushing the knob once will switch to a continuous sensitivity setting. You can use the smaller knob in the VERTICAL menu to determine vertical settings for the active channel. Press the MENU key to access advanced options.

On page 2|2 of this menu, you can add a DC offset. To activate this offset push the corresponding soft menu key. The settings window will be activated (marked in blue), and the activity indicator next to the universal knob will be illuminated. You can now set the offset value using this knob. The selected sensitivity setting determines the value of the offset. This is selected directly at the input amplifier as real voltage. The offset voltage will be added to the signal at the vertical amplifier input offsetting it by the corresponding amount from the zero position. This will be indicated by two channel markers to the left margin of the screen

(also visible if the menu has been closed). One marker indicates the position while the other marker indicates the offset (refer to Fig. 4.4). The offset is individually adjustable for each channel




Fig. 4.4: Vertical offset

Each analog channel may also be shifted in time by ± 61.5 ns. This setting is selected in the same menu and according to the same method as the DC offset. It is used to compensate different signal delays when using different cable lengths or probes.

4.3 Bandwidth Limit and Signal Inversion

Both the short menu and the advanced menu enable you to insert an analog 20 MHz low pass filter to the signal path. This will eliminate all higher frequency interference. To activate the filter in the short menu, press the respective soft menu key BWL. Once the filter is activated, the menu item will be marked in blue, and the identifier BW will be displayed in the channel information window.

Signal inversion is available in the short menu and the advanced menu in the VERTICAL section of the control panel. An activated filter will be indicated in blue in the menu and by a bar above the channel name in the channel name window.

4.4 Probe Attenuation and Unit Selection (Volt/Ampere)

The HZ350 resp. HZ355 probes supplied include an integrated part detection feature which enables the oscilloscope to promptly recognize the appropriate 10:1 divider and to display the correct values. If you are using any other probe without automatic recognition or if you connect a cable directly to the oscilloscope input, you can manually set the attenuation factor in the advanced menu in the VERTICAL section of the control panel. This is possible with the predefined steps x1, x10, x100, x1000 or, using the universal knob, as defined by the user from x0.001 to x1000.

In this menu, you can also select the unit Ampere in case you are using a current probe. If you select the unit Am-

per, the menu shows the most common factors (1V/A, 100mV/A, 10mV/A, 1mV/A). You may also use the USER setting to select any given value. This setting may also be used to measure the voltage via shunt. All measurements are always displayed with the correct unit and scale.

4.5 Threshold Setting

The advanced menu in the VERTICAL section of the control panel allows you to set a threshold. This threshold

the suggested name. You may enter up to 8 characters. Use the ACCEPT key to confirm the name in the editor. It will then be shown in the display. The name is assigned to that specific signal and will move alongside any set offset value.




Fig. 4.5: Threshold setting

defines the level to detect a High or a Low if analog channels are used as source for the serial BUS analysis or logic trigger. After selecting this soft menu item, you can set the threshold using the universal knob.

4.6 Naming a Channel




Fig. 4.6: Name selection

The last entry in the VERTICAL menu opens a submenu which allows you to enter a channel name. This name will be displayed on the grid and the printout (refer to Fig. 4.6). Your first option is to switch the display on or off. The next option includes the menu item LIBRARY. After selecting this option, you can use the universal knob to choose a name from several suggestions. The EDIT LABEL key allows you to enter a completely new name or to customize

5 Horizontal System (time base)




Fig. 5.1: Control panel of the horizontal system

In the horizontal system section, users can select time base settings for capturing, trigger time position, zoom functions, acquisition modes, marker functions and search functions.

Knobs allow you to set time base and trigger time position. A menu enables you to select the desired acquisition mode. A separate key is available to activate the zoom. Use the arrow keys ◀▶ [37] and the SET/CLR key to select marker functions.

5.1 Acquisition modes RUN and STOP

The acquisition mode can be selected with the RUN/STOP key [39]. In RUN mode signals are shown on the screen according to the selected trigger conditions, discarding previously captured signals with each new capture. If you wish to analyze a captured signal on the screen without overwriting it, capture must be stopped by pressing the RUN/STOP key. While in STOP mode, you may not capture new signals and the key is illuminated in red.

5.2 Time Base Settings

The large knob in the HORIZONTAL section of the control panel is used to change the time base. The current time base setting (e.g. "TB: 500 ns") is displayed in the upper right above the graticule. To the right of the display you can see the trigger time position in relation to the default setting. The default setting shows the trigger time position in the center of the display, with 50% of the signal display before and 50% after this trigger position. The knob X POSITION [41] allows continuous adjustment of the x position. The maximum values allowed depend on the time base setting.

Pushing the SET/CLR key resets the value to its reference position as long as the marker or search functions have not been applied. The arrow keys ◀▶ [37] allow you to change the X position by a fixed amount of 5 divisions in the respective direction. The MENU [42] key opens a menu to determine the function for the arrow keys ◀▶ [37] and the SET/CLR key. As described above, these keys allow you to set the X position. Alternatively, you can use them to mark events within the signal with the option to navigate between up to 8 markers. In the submenu NUMER.INPUT

you can enter any horizontal position directly. This menu also allows you to activate and set search functions. You can also set the TIME REFERENCE (position for the trigger reference point, from -5 divisions to +5 divisions with 0 being the center and default setting).

5.3 Acquisition modes

The acquisition modes are selected by pressing the ACQUIRE [44] key. This opens a display menu which offers the following five basic acquisition modes:

5.3.1 Roll

This acquisition mode is intended specifically for very slow signals, with the untriggered signal „rolling“ across the screen from right to left (requires signals slower than 200 kHz). The HMO uses a ring buffer to store the signal values in roll mode. Simply put, the instrument writes the first division to the first storage space, the second division to the second storage space, etc. Once the storage is full, the instrument overwrites the first storage space with the data of the most recent measurement value. This creates a „ring“ or cycle run, similar to a ticker.

The ZOOM feature is not available in the roll mode (also refer to Chap. 5.5 ZOOM Function)

5.3.2 Arithmetic

The soft menu ARITHMETIC offers following menu items:

- **REFRESH:** This mode allows the capture and display of current signals.
- **ENVELOPE:** In this mode, the display includes the normal capture of each signal and the maximum as well as the minimum values of each capture. Over time, this creates an envelope surrounding the signal.
- **AVERAGE:** In this mode, you can use the universal knob in the Cursor/Menu section of the control panel to set the number of signal periods for averaging, available in powers of 2 from 2 to 1024 (requires repetitive signals).
- **SMOOTH:** The function SMOOTH is used to calculate the mean value from several adjacent sampling points. The result is a smooth waveform. This function is used for non-periodic signals.
- **FILTER:** In this mode, you can activate a low pass filter with adjustable cut off frequency to suppress unwanted high frequency interferences. The cut off frequency can be set based on the sampling frequency. The minimum setting is 1/100 of the sampling frequency and the maximum value is 1/4 of the sampling rate. You can select this setting with the universal knob.

5.3.3 Peak Detect

This mode is used for very large time base settings to detect even short signal changes. You can also deactivate this function within the menu or you can select the automatic switching mode.

The following conditions must be met to activate the PEAK DETECT mode:

- Function HIGH RESOLUTION is deactivated
- None of the serial or parallel buses are active

During peak detection, the oscilloscope distinguishes between two types: Acquisition peak detection and memory peak detection.

Each A/D converter converts at the full sampling rate (no Interlace mode), even if results have not been written to the acquisition memory at full sampling rate (for slow time bases, for instance). If peak detection is activated, unused converter values will be evaluated to detect minimum and maximum amplitudes. During this process, the identified minimum and maximum values including sampling interval are written to the acquisition memory. As a result, the acquisition memory stores data pairs representing the signal sequence according to the sampling interval. The smallest detectable pulse is the period of the maximum sampling rate (no Interlace mode). This describes the so-called acquisition peak detection.

A hardware peak detection is not available if data is written to the acquisition memory at the ADC's maximum sample rate. For slow time bases and a repeat rate set to automatic or maximum value, not all data from the acquisition memory will display on the screen. With peak detection activated when reading out, skipped data will be used to create a minimum and maximum value. The smallest detectable pulse is the period of the sample rate used to write to the acquisition memory. This describes the so-called memory peak detection.

If one of the peak detection modes or a combination of the two are used, the corresponding detection mode is marked with „PD“ in the upper right of the display.

5.3.4 High Resolution

This mode uses Boxcar Averaging via adjacent detection points (i.e. the converter runs at the maximum sampling rate) to increase the vertical resolution to up to 10 bit. You can deactivate this function within the menu or you can select the automatic switching mode.

Averaging several adjacent sampling rates creates a value with a higher degree of accuracy than the input data. The resulting data is called high resolution data. The process of merging multiple sampling rates to one new value only allows a sampling rate that is smaller than the maximum value. If the HIGH RESOLUTION mode is activated and the current instrument setting allows the use of the HIGH RESOLUTION mode, the detection mode is marked with „HR“ in the upper right of the display.

The following requirements must be met to activate the HIGH RESOLUTION mode:

- Sampling rate is smaller than the maximum sampling rate (no Interlace mode)
- Peak detection is deactivated
- No active logic pod (POD1/POD2)
- None of the serial or parallel buses are active

By default, all functions listed above are deactivated.

5.3.5 Interpolation

With the soft menu item INTERPOLATION users can select Sinx/x, Linear or Sample-Hold as interpolation type to display acquired data points. The default setting is Sinx/x interpolation which is the best option for displaying analog signals. Linear interpolation uses a line to connect acquired data points. Sample-Hold allows a more precise assessment of the position for the acquired data points.

5.3.6 Record Mode

This soft menu item provides the following functions:

5.3.6.1 MAX. WDH.-RATE

This mode allows you to select the memory depth and sampling rate to obtain the maximum trigger repeat rate.

When using the MAX. WAVEFORM RATE mode, the oscilloscope is set to display the maximum amount of captures per second in the signal window. Each column in the signal window displays a captured date. When peak detection is activated, each column displays a pair of min/max values.

The HMO oscilloscope displays a signal window of 600 x 400 pixels (Yt without zoom). This translates into 600 data points per detection. When peak detection is activated, 600 pairs of min/max values or 1,200 data values are displayed. The memory depth corresponds to at least the displayed time window (time base x signal window grid section in horizontal direction) multiplied by the current sampling rate. The minimum value is determined by the maximum sampling rate and the maximum signal repeat rate of the oscilloscope. The displayed sampling rate corresponds to the current sampling rate divided by the amount of data skipped while reading out from the acquisition memory. If peak detection is activated, the displayed sampling rate corresponds to the current sampling rate.




Fig. 5.2: AM modulated signal with maximum repeat rate

5.3.6.2 MAX. SA. RATE

If this function is activated, the instrument always sets the maximum sampling rate while using the maximum memory available.

The MAX. SAMPLE RATE function always uses the maximum sampling rate and displays the maximum amount of




Fig.5.3: AM modulated signal with maximum sampling rate

data. Each column in the signal window displays up to 40 detected data values (limited by processor performance). How much data is currently displayed depends on the displayed time window and the current sampling rate. If peak detection is activated, each column displays up to 20 pairs of min/max values.

The memory depth always corresponds to the maximum acquisition memory. The displayed sampling rate is identical with the current sampling rate. Peak detection is used if the displayed time window contains more data than 40 * signal window columns in the acquisition memory or min/max data in the acquisition memory.

The entire oscilloscope memory can only be read out by interface if the maximum sampling rate has been activated (refer also to the HMO SCPI Manual).

5.3.6.3 AUTOMATIK:

This function is the default setting and offers the best compromise between maximum repeat rate and maximum sampling rate (selection of memory depth).

Each column in the signal window displays up to 10 captured data values. How much data is currently displayed depends on the displayed time window and the current sampling rate. When peak detection is activated, each column displays up to 5 pairs of min/max values.




Fig. 5.4: AM modulated signal with automatic setting

The memory depth is at least twice as much as the storage capacity set for the maximum repeat rate (limited by the maximum acquisition memory). The displayed sampling rate corresponds to the current sampling rate divided by the amount of data skipped while loading from the acquisition memory. If peak detection is activated, the displayed sampling rate corresponds to the current sampling rate.

All settings apply the identical current sampling rate (sampling rate used to write to the acquisition memory). In STOP mode it is also possible to change menu items. This does not impact the current memory depth but the amount of displayed data will be adjusted. Peak detection is also activated in STOP mode (time base in microseconds).

In time bases displaying each sampling point, all three settings behave identically (except used memory depth and signal update rate).

Table 5.1 displays advantages and disadvantages of each setting.

Finally, it needs to be mentioned that this menu replaces the adjustable memory depth, a standard for other manufacturers. An adjustable memory depth is intended

Setting	Advantages	Disadvantages	Application
Max. Repeat Rate	- Many captures in one image - Rare events can be detected more quickly in connection with persistence - Quick response to Operation or change in signal - Low noise band	- High aliasing risk - Low accuracy of details - Low accuracy of measurements due to reduced amount of data	- Search for rare events - Displaying modulated signals
Maximum Sampling Rate	- Maximum accuracy of details - Lowest aliasing risk - High accuracy of measurements	- Slow response to operation or change in signal - Low signal update rate - Higher visibility of noise	- For signals with high frequency parts - Assessment of small signal details
Automatic:	- Average signal update rate - Reasonably smooth operation - Good accuracy of measurements - Low noise band	Possible aliasing	Default application

Table 5.1: Advantages and disadvantages of each setting.

to allow users to understand the relation between memory depth, time base and sampling rate and to evaluate advantages and disadvantages. With this option, the oscilloscope always captures signals with the maximum sampling rate. This allows users in STOP mode to zoom in retrospectively, even at the maximum repeat rate. It is also possible to zoom out at the maximum repeat rate if the STOP mode was run at fast time bases. If a high repeat rate can only be attained by means of low memory depth (as is the case with other manufacturers) it is nearly impossible to zoom in retrospectively in STOP mode.

5.4 Interlace Mode

In interlace mode, converters (ADC) and storage units of two channels within the same interlaced group are connected. This doubles the sampling rate and the acquisition memory. Interlace groups are channels 1 and 2 and channels 3 and 4. If an interlace group is not interlace-capable, the non-interlace mode is also applied to the related group. A channel is considered active even if it has been deactivated while still serving as the trigger source. If a channel is activated, the respective LED next to the input connector is illuminated.

The following conditions must be met to activate the Interlace mode:

- No active logic pod
- None of the serial or parallel buses are active
- Logic trigger not active

If the interlace mode is possible, it will be activated automatically.
The following table displays channel configurations that allow the operation in interlace mode.

Interlace group 1		Interlace group 2	
CH1	CH2	CH3	CH4
ON	Off	Off	Off
Off	ON	Off	Off
Off	Off	ON	Off
Off	Off	Off	ON
ON	Off	ON	Off
Off	ON	ON	Off
Off	ON	Off	ON

Tab. 5.2: Channel configuration in interlace mode

5.5 ZOOM function

The HMO series features a memory depth of 2 MB per channel. This allows the user to record long and complex signals which can be analyzed in full detail with the zoom function. To activate this feature, press the ZOOM key [40](#). The screen will be divided into two sections. The upper window displays the entire time base window whereas the lower graticule shows an enlarged section of the upper window. The enlarged signal section is marked by two blue cursors in the original signal (upper window). If




Fig. 5.5: Zoom function

several channels are activated in Zoom mode, all displayed channels will be zoomed simultaneously by the same factor and at the identical position.

Fig. 5.5 displays the zoom window with 100 μs per division. The signal was captured within a time window of 12 ms. The zoom area (lower grid) also displays the parameter for zoom time base whereas time is displayed above the zoom window. Z indicates the zoom time base (zoom factor) and determines the width of the zoom area displayed in the zoom window (12 divisions x scaling per division). Tz indicates the zoom time and determines the position of the zoom area.

The time base setting in the upper right of the display is highlighted in gray while the zoom time base above the zoom window is marked in white. The large knob in the horizontal menu is used to change the zoom factor. You can also press this knob. If the knob is pushed, the time base setting is highlighted in white and the zoom time base in gray. Now the knob is available to select the time base setting. This allows you to change time base settings without having to leave the zoom mode. Pressing the knob again will highlight the cursors limiting the zoom area in white, allowing you to use the knob to change the zoom area. Now you can use the small knob in the horizontal area of the control panel to move the position of the zoomed section across the entire signal. As described above, pressing the large knob enables you to set the time base but not the zoom factor. This in turn enables the small knob to move the trigger position to define the relationship of pre- and post captures/records.

IMPORTANT:
The ZOOM function is not available in ROLL mode.

In the acquisition mode ROLL, it is generally not possible to zoom in on the memory because the signal values of the X axis are always captured with the maximum memory depth. The acquisition mode NORMAL always includes more samples in the memory than what can be shown in the display. That explains why in this mode you are able to zoom in on the memory. The same does not apply to

the values in the Y axis (amplitude). These values apply to a specified axis and can therefore also be scaled in ROLL mode.

5.6 Navigation function

The navigation function offers easy trigger time handling and allows it to be entered numerically. The soft menu keys allow you to set the trigger time to the minimum or the maximum value, for instance. You can use the soft menu key TIME REFERENCE to define where in the signal window to find the trigger point value "0". The signal is scaled by this reference point. You can use the universal knob in the Cursor/ Menu section to select the desired setting.

5.7 Marker function

Markers allow you to highlight specific positions on the screen, e.g. a rising or falling slope, an unexpected signal value or a search result. Markers can be used to identify specific signal sections to zoom in on and to analyze the data more closely.




Fig. 5.6: Marker in zoom mode

Use the soft menu to activate the marker function. Press the MENU key in the HORIZONTAL section of the control panel to open the soft menu. Use the universal knob in the menu to select MARKER. Once this mode is activated, you can press the SET/CLR key to set a time marker at the 6th time unit (the menu in the center of the grid must be deactivated). The time markers are marked by a vertical line in gray-blue. The knob X Position allows you to move the signal including the set marker. After identifying an important signal position and setting it to the center of the screen using the position knob, you can set an additional marker. This procedure allows you to mark up to 8 interesting positions within the signal. You can toggle between markers by pressing the arrow keys ◀▶ [37]. These keys also allow you to center the markers in the middle of the screen. This feature enables you to quickly compare marked signal sections in ZOOM mode.

To delete a marker, center it in the middle of the screen and press the SET/CLR key once again. You can also delete all time markers simultaneously in the marker soft menu.

5.8 Search Function

The search function in the HMO series enables you to search for all slopes, pulse widths, peaks or additional events in the detection mode that match the manually specified search criteria. Specific settings are available for each search type. Searches can be performed on any analog channel or mathematical signal. The searched time base section can be restricted by defining a level.

Press the MENU key in the HORIZONTAL section of the control panel to activate the search function in the soft menu. Use the universal knob to select the menu item SEARCH. Once this mode is activated, you can define events, e.g. a rise time with specific attributes, such as <12ns. The search function will then look for these events in STOP mode in the most current capture. Press the menu item SEARCH TYPE and use the universal knob to select the desired search criteria.

The following functions are available:

- **Slope:** Comparable to the slope trigger; this function searches for slopes in the signal. The point in time of a detected slope corresponds to the point in time when the signal leaves the set hysteresis. The soft key LEVEL selects a level for the slope detection of the search function. The search function level matches the trigger level of the slope trigger, for instance. Level and hysteresis will display in the signal window. The hysteresis determines the area that the signal has to pass until a valid slope is detected. This area also defines the rise time of the slope. It is recommended to select a sufficiently large hysteresis to reduce noise on the signal slope.
- **Pulse width:** Comparable to the pulse width trigger; this function searches for pulses with a predetermined pulse width. A pulse always consists of a rising and a falling slope. Leaving the hysteresis defines the start and end time of the pulse. The level for the search function corresponds to the trigger level of the slope trigger, for instance. Level and hysteresis will display in the signal window. The adjustable comparison type is a search criterium for the detected time event width. The pulse width is the time period between start and stop slope of the pulse.
- **Peak:** The peak search function searches for pulses within the signal. The time of the event is the maximum value of the peak.
- **Rise / fall time:** This function searches for slopes with a specific rise/fall time within the signal. The point in time of a detected slope corresponds to the point in time when the signal leaves the set hysteresis. The upper and lower level define the upper / lower position of the hysteresis. The adjusted level will display in the signal window. The adjustable comparison type is a search criterium for the detected time event width.
- **Runt:** A runt is an aborted pulse within a signal. This occurs when the rise times of the system are greater than necessary for the desired pulse width. A positive runt exceeds the lower level of the hysteresis, for instance, but does not reach the upper level. The analyzing digital

circuits of this signal fail to detect the pulse which leads to transmission errors. The pulse width of the runt is defined by the entry and exit point from the hysteresis (duration between start and stop slope of the pulse). The adjustable comparison type is a search criterium for the detected time event width. The difference defines the maximum time range by which the specified event width may vary.

Once you have selected the appropriate search type, you can choose the desired source (choose from any of the activated analog channels including mathematical channels). Use the menu item SETUP to open a submenu where you can choose the settings for the selected search criterium (e.g. greater than a specific pulse width). Some of the adjustable parameters may be dependent on the time base (for a time base of 100µs/Div the smallest time is 2µs, for 1µs/Div the corresponding time value is 20ns). If events match the search criterium, they will be highlighted. The soft menu VIEW EVENT TABLE allows you to display the search results in a table format. Use the arrow keys or the universal knob to navigate the events in STOP mode. The select option allows you to center the selected event. When the Zoom function is activated, the selected event will automatically be centered in the Zoom window.




Fig. 5.7: Search mode with event list

6 Trigger System

The consistent application of the HAMEG operating concept allows for easy use of the HMO trigger system.

Four keys are available to select one of the frequently used settings:

■ **TYPE:** selection of trigger type
EDGE (EDGE A/B), PULSE, LOGIC, VIDEO and HOLD OFF

■ **SLOPE:** type of slope

■ **SOURCE:** determines the triggers source

■ **FILTER:** determines the exact trigger conditions




Fig. 6.1: Control panel for the trigger system

Additional keys are available to select the trigger modes (AUTO, NORMAL and SINGLE).

6.1 Trigger Modes Auto, Normal and Single

The AUTO/ NORM [29] key allows you to toggle directly between the basic trigger modes. If auto mode is activated, the key is not illuminated. Pressing the key will activate NORMAL mode, and a red LED will highlight the key.

In AUTO mode, the screen always displays a signal. If a signal fulfills the trigger conditions, the oscilloscope will synchronize with this event and triggers when the set condition is met. In case of a signal that does not fulfill the trigger condition (a simple case would be direct current), the oscilloscope itself will generate a trigger event. This allows a glance at the input signals at any time, regardless of the trigger condition.

In NORMAL mode, the signal will now be captured and displayed if the trigger condition is met. In case no new signal fulfills the set trigger condition, the signal that was triggered last will be displayed. To ensure that only a signal that meets the trigger condition is detected and displayed, press the Single key to [33] activate this mode. This key is highlighted in white when the SINGLE mode is activated. The HMO detection and trigger system is now activated, indicated by a blinking RUN/STOP key [39]. If the trigger condition is fulfilled, the trigger system is activated, data is stored and the oscilloscope switches to STOP mode (the RUN/STOP key is permanently highlighted in red).

6.2 Trigger Sources

Four analog channels and the external trigger input (AC/DC) are available as trigger sources. If the optional extension with active logic probes HO3508 including 8 or 16 digital inputs is connected, up to 16 digital inputs are available as trigger source. The soft menu key AC LINE enables

you to trigger the trigger at system frequency. The trigger signal is extracted internally from the power supply.

6.3 Slope Trigger

The easiest and by far the most frequently used trigger is the slope trigger. The oscilloscope triggers if slopes that were set with the SLOPE key occur within the signal selected in the SOURCE menu. The signal slope has to pass through the set trigger level.

The trigger type Slope Trigger is selected in the Autosetup mode (AUTOSET key). If, for instance, you select the pulse trigger and press the AUTOSET key the setting will switch to Slope Trigger. The TYPE [31] key in the trigger control panel allows you to set the trigger type. This opens a menu with corresponding options. If the SLOPE type is not active (highlighted in blue), you can press the respective soft menu key to select this type. The slope type (rising, falling or both) can be set directly with the SLOPE [35] key. This will shift the setting forward by one, i.e. from rising to falling slope, to both slopes, and pressing the key yet one more time will trigger another rising slope. The center of the status line on the top of the display and the display above the SLOPE key [35] show which slope type has been selected.




Fig. 6.2: Coupling modes with slope trigger

The FILTER [36] key allows you to select how to couple the signal for the trigger circuit:

- **AUTO LEVEL:** Automatic filter setting (default setting).
- **AC:** The trigger signal is coupled via high pass filter with a minimum cut-off frequency of 5 Hz which suppresses the DC portion of the triggering signal. With a changing DC portion, the trigger level remains at the set point in the AC signal. The trigger type AUTO (AUTO/NORM key) includes the Peak-Peak mode which sets limits for the trigger in the AC signal. This setting means that the trigger condition will be met for any applied signal without having to set the level. For the trigger type NORM (AUTO/NORM key), the Peak-Peak mode is deactivated, allowing the trigger level to be moved past the peak values of the signal.
- **DC:** The trigger signal is coupled to the trigger circuit with all signal portions (AC and DC voltage). This has no impact on the triggering signal.

■ **HF:** The trigger signal is coupled via high pass filter with a minimum cut-off frequency (-3dB) of 30kHz and is automatically limited when triggering the level with normal trigger. This coupling type should only be applied to very high frequency signals.

■ **LP (low pass):** The trigger signal is coupled via low pass with a maximum cut-off frequency of 5kHz. This filter removes high frequencies and is available with AC and DC coupling.

■ **NR (noise reduction):** A low pass filter with a maximum cut-off frequency of 100MHz will improve the noise performance for the trigger amplifier. This filter removes high frequencies and is available with AC and DC coupling

The coupling types low pass and noise reduction may not be activated simultaneously.

You can use the soft menu key EDGE A/B to combine the edge trigger with a B trigger. As a result, it is possible to set the trigger to first require a completed “A” condition followed by a completed “B” condition for the trigger signal to activate the trigger. The dual soft key TRIGGER ON allows you to determine if the B event should be checked after a specified amount of time (minimum 16ns, maximum 8,58993 s) or after a specified quantity (minimum 1, maximum 65535) after the A event.

Both A trigger and B trigger can have different sources. In the SOURCE menu, you can use the soft menu key SOURCE A / SOURCE B to select the respective source via universal knob in the CURSOR/MENU control panel. You can select the analog channels and an external trigger signal (Extern) which is applied to the EXT-TRIG connector on the back panel of the instrument. Press the respective soft menu key and enter the level via universal knob in the CURSOR/MENU control panel or enter it numerically via KEYPAD button. To set the type of slope (rising, falling or both), use the respective soft menu key SLOPE A / SLOPE B.

You can select additional settings in the FILTER menu. The same filter settings are available for filter A as described above (FILTER A is highlighted in blue). For filter B (FILTER B is highlighted in blue), the coupling types DC, HF and NOISE RED. are available.

6.4 Puls Trigger

The pulse trigger allows triggering for specific pulse widths of positive or negative pulses or for pulse width ranges. The oscilloscope triggers if a pulse occurs within the signal selected in the SOURCE menu that matches the properties set in the FILTER menu. If a pulse fulfills the trigger conditions, the oscilloscope triggers on the trailing slope, i.e. for a positive pulse it triggers on the falling slope and for a negative pulse on a rising slope.

Activate the pulse trigger by pressing the TYPE key [31] in the trigger control panel. Press the FILTER key [36], then you can select additional settings for the pulse trigger in the soft menu.

There are six different settings:

- **$t_i > t$** : The pulse width t_i , which will generate the trigger is greater than the adjustable reference time t .
- **$t_i < t$** : The pulse width t_i , which will generate the trigger is less than the adjustable reference time t .
- **$t_i = t$** : The pulse width t_i , which will generate the trigger equals the adjustable reference time t . The reference time is a combination of time t plus the adjustable deviation.
- **$t_i \neq t$** : The pulse width t_i , which will generate the trigger is unequal to the adjustable reference time t . The reference time is a combination of time t plus the adjustable deviation.
- **$t_1 < t_i < t_2$** : The pulse width t_i which will generate the trigger is less than the adjustable reference time t_2 and greater than the adjustable reference time t_1 .
- **$\text{not}(t_1 < t_i < t_2)$** : The pulse width which will generate the trigger is greater than the adjustable reference time t_2 and less than the adjustable reference time t_1 .

The comparison time can be set anywhere between 8 ns to 134.217 ms. For any value up to 1 ms the resolution is 8 ns and for any value greater than 1 ms the resolution is 1 μ s. The deviation can be set anywhere between 4 ns to 262.144 μ s with a resolution of 4 ns.




Fig. 6.3: Menu for pulse trigger settings

Select the desired function and then adjust the desired reference time. If you select " $t_i \neq t$ " or " $t_i = t$ " you can use the soft menu key TIME and the universal knob in the CURSOR/MENU control panel to set a reference time. Selecting the soft menu item DEVIATION allows you to use the universal knob to define a tolerance zone. Selecting " $t_1 < t_i < t_2$ " or " $\text{Not}(t_1 < t_i < t_2)$ " allows you to define both reference times with the menu items TIME 1 and TIME 2. Selecting " $t_i < t$ " or " $t_i > t$ " allows you to define only one limit. Selecting the corresponding soft menu item allows you to set any of these settings for positively or negatively polarized pulses. For the associated positive pulse, you define the width from rising to falling slopes, and accordingly for the associated negative pulse from falling to rising slopes. As is consistent with the principle, triggering always occurs on the second slope of the pulse.

6.5 Logic Trigger

You may test all settings in the logic trigger without any active logic probes HO3508 connected; however, the settings will only be effective when a HO3508 is connected.

Selecting the logic trigger in the soft menu after pressing the TYPE key [31] will switch the trigger source to the digital inputs. Pressing the SOURCE key [32] after selecting this trigger type displays a soft menu for additional settings and a window to list these settings (see Fig. 6.4).




Fig. 6.4: Menu for logic trigger settings

The top soft menu key enables you to select a logic channel for which you wish to determine the trigger condition. Use the universal knob for this purpose. In the general menu, the selected digital input is marked with a blue background. In the field, the trigger level is marked as High (H), Low (L) or (X). Use the corresponding soft menu key to select the trigger level. As before, the selected level will be marked in the soft menu with a blue background. Another soft menu item allows the logic combination of the digital channels. They can be combined by logic AND or OR. If AND is selected, the set conditions of all channels must be met simultaneously for the input signal so that the combination produces a logic High (H) as a result. If OR is selected, at least one of the defined level conditions must be met. The last item in this menu is the option TRIGGER ON. Use the soft menu key to select TRUE or FALSE. This allows you to preselect whether the trigger will be generated at the beginning (TRUE) or the end of the logic condition (FALSE).

After selecting the desired set of conditions, you can use the FILTER key [36] for additional settings. A soft menu will open allowing you to add a time limit to the TRIGGER ON option (this menu shows the condition selected in the SOURCE menu). Press the top soft menu key to add a time limit. This option compares the duration of the output signal for the combination of the logic conditions to the set duration t_i . If the duration is identical or not identical, you can set the deviation Δt . If t is within these parameters, the trigger condition has been met. The menu field below allows the selection of the comparison criteria.

The following six criteria are available:

- **$t_i \neq t$:** The duration of the applied bit pattern which will generate the trigger is unequal to the adjustable reference time.
- **$t_i = t$:** The duration of the applied bit pattern which will generate the trigger is equal to the adjustable reference time.
- **$t_i < t$:** The duration of the applied bit pattern which will generate the trigger is less than the adjustable reference time
- **$t_i > t$:** The duration of the applied bit pattern which will generate the trigger is greater than the adjustable reference time.
- **$t_1 < t_i < t_2$:** The pulse width t_i which will generate the trigger is less than the adjustable reference time t_2 and greater than the adjustable reference time t_1 .
- **$\text{not}(t_1 < t_i < t_2)$:** The pulse width which will generate the trigger is greater than the adjustable reference time t_2 and less than the adjustable reference time t_1 .

As with the pulse trigger, for $t_i \neq t$ or $t_i = t$ you can set a reference time with the soft menu key TIME and the universal knob. Selecting the soft menu item DEVIATION allows you to use the universal knob in the CURSOR/MENU control panel to set the deviation Δt which defines the tolerance between set reference time t and valid and real pulse width t_i (permissible tolerance range). Selecting " $t_1 < t_i < t_2$ " or " $\text{not}(t_1 < t_i < t_2)$ " allows you to set both comparison times (time interval limits) with the soft menu items TIME 1 and TIME 2. For $t_i < t$ or $t_i > t$, only one limit can be defined. Time and deviation can be set with the universal knob or the KEYPAD button in the CURSOR/MENU control panel.




Fig. 6.5: Logic channels' settings display

To change the threshold values for the logic states "one" and "zero", it is necessary to use settings in the channel menu (MENU key in the VERTICAL control panel). Select the desired POD (POD1 with key CH3/POD1 [24], POD2 with key CH4/POD1 [25]). This is a dual soft key. Pressing the key allows you to toggle between the conditions, with the active condition highlighted by a background in the respective channel color. If logic mode is already activated, the digital channels will be displayed in the channel display section of the display (framed and marked with

"POD1:xxxV" or "POD2:xxxV"). Pressing the MENU key [21] in the VERTICAL section of the control panel allows you to activate one of five predefined logic levels. Three of these are fixed for TTL, CMOS and ECL. After pressing the respective menu item, two customize d logic levels may be set from -2V to 8V with the universal knob. The soft menu key RESET POS. & SIZE activates the display for all digital channels of the selected group by using default values for the vertical position and size. You may also define the name for the current signal by using the soft menu NAME. A library provides a list of predefined names. The name can be activated, deactivated or edited.

6.6 Hold Off

The trigger hold off time indicates how long after a trigger the HMO oscilloscope waits until the trigger system is ready again. The trigger system is active again only after the trigger hold off time has expired. This allows the function to guarantee stable triggering in case unwanted events are triggered. Ideally, the hold off time is used to trigger on periodic signals with several slopee.

Changing the time base does not impact the selected hold off time.

HOLD OFF is a dual soft menu key. If the top section of the soft menu key is active (highlighted in blue), a value can be entered in the CURSOR/MENU control panel via universal knob or numerically via KEYPAD button. You may enter any value between 50ns and 10s. The bottom section of the soft menu key OFF (highlighted in blue) allows you to deactivate the function HOLD OFF.

6.7 Video Trigger

The video trigger allows you to trigger on PAL, NTSC SECAM standard video signals or on HDTV signals. Select the video trigger mode by pressing the key TYPE [31] in the trigger section of the control panel. Select the source by pressing the SOURCE [32] key. The FILTER [36] menu allows




Fig. 6.6: Video trigger menu

you to define additional settings. The oscilloscope triggers if the CVBS signal (Color Video Baseband Signal) selected

in the SOURCE menu features the attributes set in the FILTER menu.

Select the desired standard by pressing the respective soft menu key STANDARD. Use the universal knob in the CURSOR/MENU control panel or press the soft menu key again to select the desired standard. The second setting will apply to the polarity of the sync pulse (may be positive or negative). With positive video modulation (the highest brightness is represented in the image by the maximum signal voltage), the synchronization pulses are negative, with negative modulation they are positive. The slopes of the synchronization pulses are used for triggering which explains why a faulty polarity setting causes irregular triggering by image information. Next you can select between frame triggering (FRAME) and line triggering (LINE). Selecting LINE allows you to define the exact line between 1 and 625 via universal knob or the KEYPAD button in the CURSOR/MENU control panel.

The soft menu item ALL LINES enables the oscilloscope to trigger on the start of the lines in the video signal. This key selects all lines i.e. even when other trigger conditions are met, the oscilloscope will trigger on each line. If FRAME is selected for frame triggering, the lower menu items will allow to trigger on ODD or only EVEN half frames. In this case, the oscilloscope will trigger on the start of the half frames in the video signal. The respective key will select the odd (even) half frames, i.e. even if the other trigger conditions are met, the oscilloscope will trigger on each odd (even) half frame.

The following modes are available:

- PAL, NTSC, SECAM, PAL-M and
- SDTV 576i Interlaced
- HDTV 720p Progressive
- HDTV 1080p Progressive
- HDTV 1080i Interlaced

7 Signal Display

The following chapter describes the selection and display of signals from various sources as well as all available display modes

7.1 Display Settings

The HMO series features a high quality TFT display with VGA (640x480 pixels resolution) including LED backlighting. Basic display settings can be defined by pressing the DISPLAY **[14]** key in the GENERAL control panel. When the soft menu item VIRTUAL SCREEN is activated, a scroll bar will display to the right of the display graticule. Use the universal knob to upload and download the display window within the 20 divisions of the virtual screen. You will find a detailed description of the VIRTUAL SCREEN option in the next chapter.

The following settings can be selected:

- **DOTS ONLY:** If this option is activated (ON), only the acquired data points will be shown. This means that the data points of all signals will not be connected by vertical lines. If this option is deactivated (OFF), interpolated data points will also be shown.
- **INVERSE BRIGHTN.:** This setting inverts the brightness of the displayed signals. Normally, frequently captured dots will be displayed more brightly than rare dots. The INVERSE BRIGHTNESS option reverses the circumstances. Rare events display a higher brightness compared to frequent events. To capture rare events in a signal, this setting can be used in combination with persistence.
- **FALSE COLORS:** This setting converts the brightness levels of the displayed signals to a color scale (ranging anywhere from blue, magenta, red and yellow to white). Thanks to the higher contrast, users can view signal details more easily. This setting applies to all signals simultaneously.
- **GRID:** This soft menu allows you to display the graticule as LINES (the graticule is divided into horizontal and vertical divisions), as CENTER CROSS (displays one horizontal and one vertical zero line, showing the divisions as dots) or as OFF (the entire graticule will include no dots or lines).
- **INFO WINDOWS:** Selecting this soft menu item will open a submenu which allows you to set the transparency for the info windows. Info windows are small windows that appear on the screen depending on the particular application (e.g. values are displayed when offset is changed). A transparency value of 0% to 100% is selectable. Use the universal knob **[4]** to define this setting. Additional menu items allow you to activate or deactivate the info windows for POSITION and TRACE BRIGHTN.. If POSITION is activated and the vertical position is changed, the respective value on the zero line will be displayed. Depending on the selected trigger type, the user will see specific information about the acquisition

status. This information will only be displayed if the signal changes on the screen can persist over a longer period. If the trigger condition has been met, the information window shows a progress display for the post-trigger and pre-trigger. If the trigger condition has not been met, the information window shows the time of the last trigger event (Trig?). If the trigger type AUTOMATIC is selected, the instrument will switch to non-triggered acquisition mode in case of a non-triggered condition over an extended period of time. This acquisition mode does not display an info window as the data currently captured is displayed.

AUX. CURSORS: This soft menu allows you to define the settings for auxiliary cursors. Pressing the function keys enables you to activate or deactivate the cursors. The menu item DEFAULTS resets the default settings.

7.2 Usage of the Virtual Screen

The graticule for the HMO series includes 8 vertical divisions but also has a virtual range of 20 divisions. These 20 divisions may be used entirely by the optional digital channels D0 to D15, the mathematical channels and the references signals. The analog channels may use up to ± 5 divisions from the center.




Fig. 7.1: Drawing of the virtual screen area and an example

Fig. 7.1 illustrates the functionality of the virtual screen. The display includes a section of 8 vertical divisions in gray. This section enables you to display analog signals. The small bar next to the graticule indicates the position of the 8 visible divisions within the available 20 divisions. By pressing the SCROLL BAR [5] the bar will be activated and displayed in blue and you can use the universal knob to shift the 8 visible divisions (gray section) within the available 20 divisions. This allows a simple and clear display of many individual signal portions.

7.3 Signal Intensity Display and Persistence Function

The default setting (indicated as active when the INTENS/PERSIST [7] key is illuminated in white) allows you to use the universal knob to change the intensity of the signal display to anywhere from 0% to 100%. Persistence mode allows the display of varying signals by enabling the inst-

ument to write several signals on the display simultaneously. It is also possible to induce accelerated aging of signals with an adjustable persistence from 50ms to infinite. Signals occurring less frequently will be displayed in darker color and signals occurring more frequently will be displayed in lighter color. Press the INTENS/PERSIST key in the soft menu to select this mode.




Fig. 7.2: Menu for setting the signal display intensities

The soft menu items GRID and BACKLIGHT allow you to use the universal knob to adjust the grid intensity and the backlighting. The soft menu key LED BRIGHTNESS allows you to toggle between bright (Bright) and dark luminescent (Dark) LEDs. This setting affects the brightness of the channel status LEDs and all illuminated keys on the front panel.

The soft menu SETTINGS allows you to select the persistence settings for the signals on the screen. The persistence function ensures that signals will not be replaced when the screen is updated. Instead, the signals will pause for a specific amount of time and then slowly begin to fade. This type of display is very similar to that of an analog oscilloscope.




Fig. 7.3: Persistence function

There are three possible settings for the duration of the persistence: Off, Automatic and MANUAL. The option MANUAL allows you to set a duration of 50ms to infinite by using the universal knob. If a finite duration was selected,

new signals will be written on top of one another within this timeframe where the most recent captures will be displayed more brightly than older signals. For instance, if 300ms is selected, the display for the signal curves will become darker in 50ms intervals and will be erased after 300ms. The AUTOMATIC setting allows you to select the automatic configuration of the persistence. If this setting is activated, the instrument attempts to select the optimal time. If OFF is selected, the persistence function is deactivated. Another available option is the BACKGROUND function. With this key, you can activate or deactivate a mode which allows older signal curves to not disappear entirely after the set persistence time. Instead, these signals will continue to be displayed in the background with low brightness. This display is useful for the analysis of peak values in signals, for instance.

7.4 XY Display




Fig. 7.4: Settings in the X-Y menu

The HMO series features a key that allows you to switch directly to the XY display. Two signals will be displayed simultaneously, one in Y direction and one in X direction. This implicates that the time base X will be replaced by amplitude values of a secondsource. The resulting signal curves for harmonic signals are known as Lissajous figures and allow the analysis of frequency and phase position for these two signals. In case of a nearly identical frequency the figure will rotate. If the frequency is exactly identical, the figure will stand still and the phase position can be deduced from its shape. You can activate the XY display by pressing the XY key [19] in the VERTICAL section of the control panel. The key will be illuminated and the display will be divided into one large and three small display areas.

The following settings apply exclusively to the four channel instruments. The two channel instruments only supports the simple XY display.

The large grid shows the XY display while the small grids show the source for X, Y1, Y2 and Z. The small windows feature the classical signal display as Y vs. time. It is possible to define two signals as the Y input and display this vs. the x input to perform a comparison. It is necessary to show the menu to determine which input signal is de-

fined as X, Y1, Y2 or Z. To do so, press the XY key again. The menu that opens allows you to assign X, Y1 and Y2 accordingly.

Press the soft menu key ZSETTINGS to determine the settings for the Z input. The function SOURCE Z allows you to use any of the analog channels as source for the Z input. Use the universal knob to select the desired setting. The Z input allows you to control the brightness of the XY signal. This can be static or dynamic, by setting an adjustable threshold or by modulating the brightness with the amplitude change of the Z input. In the MODULATION setting, large amplitudes of the Z source will display the XY points. The transition is continuous. The setting On|Off displays values below the selected threshold of the Z source and the XY points with the lowest brightness (ON/OFF). Values exceeding the threshold will be displayed with the selected brightness. There is no transition between the two states. You can use the universal knob or the KEYPAD button to select the threshold.




Fig. 7.5: Settings for the Z input

The XY display will be deactivated by pressing the XY key in the VERTICAL section of the control panel if the XY settings are activated. If you wish to show no menu or a different menu, press the XY key twice to deactivate the XY display.

8 Measurements

There are two different types of measurements on signals: cursor measurements and automatic measurements. All measurements are stored in a buffer memory that is larger than the display memory. The integrated hardware counter shows the frequency and period duration for the selected input.

8.1 Cursor Measurements

The measurement option that is most frequently used with an oscilloscope is the cursor measurement. The concept for this function is based on the expected measurement results. This is reflected by the availability of not only one or two cursors but even three cursors in some measurement modes. To control cursor measurements, you may use the keys CURSOR MEASURE and KEYPAD as well as the universal knob. The measurement type can be defined in the menu that opens when you press the CURSOR MEASURE key.

The menu CURSOR MEASURE allows you to select cursor-based measurements for an activated signal source on the oscilloscope. The measurement source is indicated by the font color of the respective result. The results are displayed at the bottom of the screen. If "n/a" is displayed, the measurement is not applicable to the signal. For instance, this may be the case for a voltage measurement on a POD because only logic states without voltage reference are displayed here. If "?" is displayed, the display does not show a complete measurement result. For instance, the period to be measured may not display completely and can consequently not be identified.




Fig. 8.1: Selection menu for cursor measurements

As shown above, the measurement type can be selected by pressing the respective soft menu key and the cursor measurement type can be selected by using the universal knob. The measurement results are displayed at the bottom of the screen. To move cursors, press the universal knob and position the cursor by turning the universal knob.

The measurement types have the following functions:

VOLTAGE

This mode provides two cursors to measure three different voltages. The values V_1 and V_2 correspond to the voltage between the zero base line of the selected signal and the current position of the first or second cursor. The value ΔV corresponds to the amount of voltage between the two cursors.

TIME

This mode provides two cursors to measure three different times and an equivalent frequency. The values t_1 and t_2 correspond to the time between the trigger and the current position of the first or second cursor. The value Δt corresponds to the amount of time between the two cursors.

RATIO X

This mode provides three cursors to measure a ratio in X direction (e.g. a duty ratio) between the first two cursors and the first and the third cursor. The measurement values are displayed in four different formats (floating point, percent, degrees and radians).

RATIO Y

This mode provides three cursors to measure a ratio in Y direction (e.g. an overshoot) between the first two cursors and the first and the third cursor. The measurement values are displayed in two different formats (floating point and percent).

COUNT

This mode provides three cursors to count signal changes that exceed the threshold within a specific interval. The interval may be set by using the first two cursors and the threshold may be set by using the third cursor. The measurement values are displayed in four different formats (number of rising and falling slopes and number of positive and negative pulses).

PEAK VALUES

This mode provides two cursors to measure the minimum and the maximum voltage of a signal within the interval set by using both cursors. The values V_{p-} and V_{p+} correspond to the minimum and the maximum voltage. The peak value (V_{pp}) corresponds to the amount of voltage between the minimum and maximum value.

RMS, MEAN, STANDARD DEVIATION σ

This mode provides two cursors to measure the effective value (RMS – Root Mean Square), the mean value and the standard deviation within the interval set by using both cursors.

DUTY RATIO

This mode provides three cursors to determine the duty ratio between the two horizontal cursors. The third cursor is used to specify the threshold at which the duty ratio is measured.

RISE TIME

This mode provides two cursors to automatically measure the rise and fall time of each slope to the far left within the interval set by using both cursors.

V MARKER

This mode provides two cursors to measure three different voltages and a time. The values V1 and V2 correspond to the voltage between the zero base line of the selected curve and the current position of the first or second cursor. The value ΔV corresponds to the amount of voltage between the two cursors. The value Δt corresponds to the amount of time between the two cursors.

If the function AUTOM. SOURCE is activated (On), the currently targeted channel will be used as source for the measurement. If the setting is deactivated (Off), the channel set under SOURCE will be applied even if it is not targeted. The soft menu key SOURCE allows you to select a source for the measurement by using the universal knob. Pressing the soft menu key SET TO TRACE places the selected cursors in their optimal position on the signal curve. This allows very fast and typically optimal automatic positioning of the cursors. For the most part, only fine tuning is required at this point and the tedious major adjustments to the cursors will no longer be necessary. As previously described, the cursors can also be selected by pressing the universal knob and may be positioned by turning the universal knob. In case the automated function SET TO TRACE does not provide the anticipated results due to complex signals, you can press the key SET TO TRACE to position the cursors in a predefined starting position. This allows you to return distant cursors to the screen.

The soft menu key GLUE TO TRACE allows cursors to stay on the selected data point without changing the position in the measurement signal even if the scaling is modified (cursors will be „glued“ to the signal). This function can be activated or deactivated. If this mode is deactivated, the cursor stays in position on the screen if scaling occurs. With GLUE TO TRACE deactivated, the measured value changes while it remains unmodified when the mode is activated.

8.2 Automatic Measurements

The HMO series features cursor measurements and also various automatic measurements. These may be activated by pressing the key AUTO MEASURE  in the section ANALYZE of the control panel.

This menu allows you to select up to six automatic measurement functions by using the soft menu key MEAS. PLACE and the universal knob. A maximum of two measurements are possible simultaneously. These may originate from two different sources. The measurement source (soft menu SOURCE) is indicated by the font color of the respective result. The results are displayed at the bottom of the screen. If “n/a” is displayed, the measurement is not




Fig. 8.2: Menu for the automatic measurements settings

applicable to the signal. For instance, this may be the case for a voltage measurement on a POD because only logic states without voltage reference are displayed here. If “?” is displayed, the display does not show a complete measurement result. For instance, the period to be measured may not display completely and can consequently not be identified.

The list of available sources only includes displayed channels (possible sources are analog, digital and mathematical channels).

The following measurement types are available: MEAN

This mode measures the mean value of the signal amplitude. If the signal is periodic, the first period on the left of the screen will be used for the measurement. The measurement will only be applied to the selected channel.

RMS

This mode identifies the effective value from the displayed view of the signal. If the signal is periodic, the first period on the left of the screen will be used for the measurement. The effective value is not applied to a sine signal will be calculated directly (so-called TrueRMS). The measurement will only be applied to the selected channel.

PEAK-TO-PEAK

This mode measures the difference in voltage between the maximum and the minimum peak value of the signal within the displayed view.

PEAK +

This mode measures the maximum voltage value in the displayed view of the screen. The measurement will only be applied to the selected channel.

PEAK –

This mode measures the minimum voltage value in the displayed view of the screen. The measurement will only be applied to the selected channel.

FREQUENCY

This mode identifies the frequency of the signal from the reciprocal value of the first signal period T . The measurement will only be applied to the selected channel.

PERIOD

This mode measures the duration of the signal period T . The period identifies the duration between two equal values of one periodically repeated signal.

AMPLITUDE

This mode measures the amplitude of a square wave signal. This mode calculates the difference in voltage between the upper and the lower level (V_{base} and V_{top}). The measurement will only be applied to the selected channel and requires a minimum of one complete period of a triggered signal.

UPPER LEVEL

This mode measures the mean voltage level of an upper square wave. This mode calculates the mean value of the slope (without overshoot). The measurement will only be applied to the selected channel and requires a minimum of one complete period of a triggered signal.

LOWER LEVEL

This mode measures the mean voltage level of the lower square wave. This mode calculates the mean value of the slope (without overshoot). The measurement will only be applied to the selected channel and requires a minimum of one complete period of a triggered signal.

PULSE WIDTH +

This mode measures the width of the positive pulse. A positive pulse consists of a rising slope followed by a falling slope. This measurement type identifies the two slopes and calculates the pulse width from their time difference. The measurement will only be applied to the selected channel and requires a minimum of one completely displayed period of a triggered signal.

PULSE WIDTH –

This mode measures the width of the negative pulse. A negative pulse consists of a falling slope followed by a rising slope. This measurement type identifies the two slopes and calculates the pulse width from their time difference. The measurement will only be applied to the selected channel and requires a minimum of one completely displayed period of a triggered signal.

DUTY RATIO +

This mode measures the positive duty ratio. In this mode, positive signal portions are identified over a specific period and will then be analyzed in relation to the signal period. The measurement will only be applied to the selected channel and requires a minimum of one complete period of a triggered signal.

DUTY RATIO –

This mode measures the negative duty ratio. In this mode, positive negative portions are identified over a specific period and will then be analyzed in relation to the signal period. The measurement will only be applied to the selected channel and requires a minimum of one complete period of a triggered signal.

RISE TIME 90%

This mode measures the rise time of the first rising slope in the displayed view of the screen. The rise time identifies the time in which the signal rises from 10% to 90% of its amplitude.

FALL TIME 90%

This mode measures the fall time of the first falling slope in the displayed view of the screen. The fall time identifies the time in which the signal falls from 90% to 10% of its amplitude.

RISE TIME 80%

This mode measures the rise time of the first rising slope in the displayed view of the screen. The rise time identifies the time in which the signal rises from 20% to 80% of its amplitude.

FALL TIME 80%

This mode measures the fall time of the first falling slope in the displayed view of the screen. The fall time identifies the time in which the signal falls from 80% to 20% of its amplitude.

 σ -STD. DEVIATION

This mode measures the standard deviation of the signal amplitude in the displayed view of the screen. The standard deviation is the measurement for the deviation of a signal from its mean value. A low result indicates that the values are close to the mean value. A higher result illustrates that on average the difference between the values is greater.

DELAY

This mode measures the time delay between the set measurement source and the reference source. This mode searches for the slope of the measurement source that is closest to the time reference. Then, beginning from this point, it searches for the nearest slope of the reference source. This time difference indicates the measurement result. A submenu (DELAY SETTINGS) allows you to select the setting for measurement source, reference source and slopes.

PHASE

This mode measures the phase between two slopes of two channels in the displayed view of the screen. This mode measures the relation of the time delay between the set sources to the signal period of the measurement source. This mode searches for the slope of the measurement source that is closest to the time reference. Then,

Measurements

beginning from this point, it searches for the nearest slope of the reference source. The time difference and the signal period indicate the measurement result in degrees. A sub-menu (MEASUREMENT SOURCE/ REFERENCE SOURCE) allows you to select the measurement source and the reference source.

COUNT +

This mode counts positive pulses in the displayed view of the screen. A positive pulse consists of a rising slope followed by a falling slope. The mean value is calculated from the amplitude of the measurement signal. A slope will be counted if the signal runs through the mean value. A pulse that passes the mean value only once will not be calculated. The measurement will only be applied to the selected channel.

COUNT -

This mode counts negative pulses in the displayed view of the screen. A negative pulse consists of a falling slope followed by a rising slope. The mean value is calculated from the amplitude of the measurement signal. A slope will be counted if the signal runs through the mean value. A pulse that passes the mean value only once will not be calculated. The measurement will only be applied to the selected channel.

COUNT +/-

This mode counts signal changes (slopes) from Low Level to High Level in the displayed view of the screen. The mean value is calculated from the amplitude of the measurement signal. A slope will be counted if the signal runs through the mean value. The measurement will only be applied to the selected channel.

COUNT -/

This mode counts signal changes (slopes) from High Level to Low Level in the displayed view of the screen. The mean value is calculated from the amplitude of the measurement signal. A slope will be counted if the signal runs through the mean value. The measurement will only be applied to the selected channel.

TRIGGER FREQUENCY

This mode measures the frequency of the trigger signal bases on the period duration. The source for the measurement is the currently set trigger source. The frequency will be determined with a hardware counter with a high accuracy of 6 digits.

TRIGGER PERIOD

This mode measures the duration of periods of the trigger signal (with a hardware counter).

8.2.1 Statistics for Automatic Measurements

If automatic measurement functions are defined, you can view statistics for these parameters on page 2|2 of the AUTO MEASURE menu. The statistics allow you to evaluate a periodic signal over a number of measurements.

The results (current value, minimum, maximum, mean value, standard deviation and number of measurements) are shown in table format in the display window. Statistics are available for up to 1,000 captures, and you can define the desired number with the universal knob. The mean value and the standard deviation are identified by means of the most current n values where n corresponds to the set captures (soft menu key NO. OF AVERAGES). Minimum and maximum of the measurement value applies to the total number of measurements. The total number of measurements will be displayed in the statistics. The key RESET STATISTIC resets the statistics. All recorded values are erased. This function can be used to restart the statistics at a defined point. The key CLEAR MEASUREMENTS deactivates the automatic measurements.




Fig. 8.3: Statistics for automatic measurements

9 Analysis

The HMO series oscilloscopes features an analysis function for the collected data records which are displayed on the screen. Simple mathematical functions can be performed with the function “Quick Mathematics” while more complex functions and the linking of functions can be accomplished with the formula editor. The MATH menu includes mathematical functions for the recorded signal types. The mathematical functions track the changes of the included signals and only apply to the visible area. You can also activate the frequency analysis (FFT) by pressing the respective key. The function QUICKVIEW provides a quick overview for the signal properties. A masked-based PASS/FAIL test allows you to monitor signals automatically.

9.1 Mathematical Functions

The MATH menu includes mathematical functions for the recorded signal types. The mathematical functions track the changes of the included signals and only apply to the visible area of the screen. If a signal is cut off at the edge




Fig. 9.1: Mathematics short menu

of the screen may indicate that the corresponding mathematical curve is also truncated. The DIV encoder can be used to scale an activated mathematical curve.

The MATH menu is divided into Quick Mathematics and formula sets. Quick Mathematics is designed for simple and quick calculations. The formula sets, however, allow more complicated links.

9.1.1 Quick Mathematics

Pressing the MATH key **[26]** in the VERTICAL control panel will activate a short menu. The lowest soft menu key QM/MA activates Quick Mathematics or the formula editor. QM stands for Quick Mathematics and MA for die Mathematics Advanced (formula editor). You can toggle between the two mathematical functions by pressing this soft menu key.

The soft menu keys in the QM menu allow you to configure the Quick Mathematics function. With the first and the third soft menu key, you can choose the respective chan-




Fig. 9.2: Quick Mathematics menu

nel (source) for the Quick Mathematics calculation. You may only choose activated analog channels. The central soft menu key allows you to select the calculation type addition (ADD), subtraction (SUB), multiplication (MUL) or division (DIV). Pressing the MENU key in the VERTICAL control panel will switch you to a more detailed display of the QM menu. You can use the universal knob to select operands and operators.

9.1.2 Formula Editor

The formula editor menu (soft menu key MA) allows you to activate and deactivate mathematical equations that are defined and displayed within the selected formula set.




Fig. 9.3: Formula editor for formula sets

The list only includes visible equations. Four out of five functions from the current formula set can be displayed simultaneously. The 5th curve may be used as operand for one of the four mathematical curves. It will be calculated, but will not be included in the display. The MENU key in the VERTICAL control panel opens a menu to select the formula set and its corresponding formulas. You can also choose a NAME with a maximum of 8 characters, load a formula set (from the internal memory or from a USB stick)

or save a formula set (internally or on a USB stick). You can use the universal knob to enter the name of your choice and you can save it by using the ACCEPT key. The name will now be displayed instead of the generic labels MA1... MA5. You can specify the names for all equations separately. Once all equations, constants and names have been entered, you may also choose a name for this formula set by pressing the NAME key in the formula set menu and entering the name of your choice.



Fig. 9.4: Entry of constants and units

The HMO series includes five mathematical formula sets. Each of these formula sets contains five formulas which may be edited with a formula editor to also define linked mathematical functions. These are labeled MA1 to MA5. You can use the universal knob to select the formula set. The formula set editor (soft menu key EDIT FORMULARY) lists all existing equations which may be edited. A blue bar indicates that an equation is selected. It is important to distinguish between editing the display and editing the parameters. Use the universal knob to select the respective equation and activate it by pressing the soft menu key VISIBLE. An activated, visible equation is marked by a filled-in eye symbol in the formula editor and is listed in the short menu.

In the soft menu UNIT you can use the universal knob to select from the following units:

■ V (Volt)	■ K (Kilo, 10 ³)
■ A (Ampere)	■ M (Mega, 10 ⁶)
■ Ω (Ohm)	■ G (Giga, 10 ⁹)
■ V/A (Volt per Ampere)	■ T (Tera, 10 ¹²)
■ W (Watt)	■ P (Peta, 10 ¹⁵)
■ VA (Volt Ampere)	■ E (Exa, 10 ¹⁸)
■ VAR (reactive power)	■ Z (Zetta, 10 ²¹)
■ dB (dezibel)	■ Y (Yotta, 10 ²⁴)
■ m (Milli, 10 ⁻³)	■ dBm (dezibel milliwatt)
■ µ (Mikro, 10 ⁻⁶)	■ dBV (dezibel Volt)
■ n (Nano, 10 ⁻⁹)	■ s (second)
■ p (Piko, 10 ⁻¹²)	■ Hz (Hertz)
■ f (Femto, 10 ⁻¹⁵)	■ F (Farad)
■ a (Atto, 10 ⁻¹⁸)	■ H (Henry)
■ z (Zepto, 10 ⁻²¹)	■ % (percent)
■ y (Yokto, 10 ⁻²⁴)	■ ° (degree)

■ π (Pi)	■ T (Tesla)
■ Pa (Pascal)	■ (dez) (decimal)
■ m (Meter)	■ (bin) (binary)
■ g (Acceleration)	■ (hex) (hexadecimal)
■ °C (degrees Celsius)	■ (oct) (octal)
■ K (Kelvin)	■ DIV (Division, division)
■ °F (degrees Fahrenheit)	■ px (pixel)
■ N (Newton)	■ Bit (Bit)
■ J (Joule)	■ Bd (Baud)
■ C (Coulomb)	■ Sa (Sample)
■ Wb (Weber)	

The unit selected for the equation will be applied to the channel description, cursor types and automatic measurement types. The equation name is listed in the formula set editor and is used as label in the curve window. The soft menu key DELETE removes the equation from the formula set.

An equation consists of an operator (mathematical function) and up to two operands. You can use the universal knob to choose one of the following operators:

■ Addition	■ Neg. Wave
■ Subtraction	■ Reciprocal
■ Multiplication	■ Inverted
■ Division	■ Common logarithm
■ Maximum	■ Natural logarithm
■ Minimum	■ Derivation
■ Square	■ Integral
■ Root	■ IIR Low Pass Filter
■ Amount	■ IIR High Pass Filter
■ Pos. Wave	

For each corresponding equation, the input channels CH1, CH2, CH3, CH4 and an adjustable constant are allowed as OPERAND (sources). For the formula MA2, MA1 is added as source, for MA3 the added source is MA2, for MA4 it is MA3 and finally for MA5 the added source is MA4. From these five equations, you can create, save and retrieve a total of five different sets. New equations can be added by using the universal knob to select the menu item NEW in the formula set editor. Pressing the soft menu key ADD allows you to edit the new equation.

Fig. 9.4 illustrates how in formula MA1 channel 1 is added with 100µA. Press the key EDIT CONSTANT in the menu for entering constants and use the universal knob to choose from the following constants:

■ Pi
■ 2x Pi
■ 0,5 x Pi
■ User 1 . . . 10 (up to 10 customized constants are available)

For instance, if you select USER1 as constant, you can press the soft menu key VALUE and use the universal knob to select a numeric value. You can apply the same method to set a DECIMAL POINT and enter an additional S prefix (soft menu key PREFIX). You may choose a UNIT

from the same SI prefixes as those that are available in the soft menu EDIT. Press SAVE to store these settings as USER 1 and return to the menu to edit the equation. You can store up to 10 of these customized constants. When saving a formula set, you may also add a comment (soft menu key COMMENT). Press the key SAVE to save this formula set with the determined name and comment to the selected location.

Stored formula sets may be reloaded at any time. Press the MATH key to activate the Mathematics menu and then press the MENU key below the SCALE VOLTS/DIV key. This menu displays the menu item LOAD. This will start the file manager which will display the internal memory or the connected USB stick as possible storage location. Select the respective formula set file and press the key LOAD to load the file.

9.2 Frequency Analysis (FFT)

In general, the FFT in an oscilloscope works differently than in a spectrum analyzer and is affected not only by the time base setting, but also by the available number of used acquired data points when calculating the FFT. The HMO series allows you to include up to 65k point in the FFT resulting in a very high resolution for this price bracket.

The FFT is not suitable for the analysis of very slow signals (Hz-range); this type of analysis requires a classic oscilloscope mode.

The FFT menu allows a quick Fourier transformation which displays the frequency spectrum of the measured signal. The changed display allows you to determine the most frequent frequencies in the signal and the corresponding amplitude.




Fig. 9.5: FFT illustration

You can activate the frequency analysis by pressing the FFT key **[g]** in the ANALYZE section of the control panel. Once the key was pressed, it will be illuminated in white and the screen will be divided into two graticules. The upper section displays the voltage time curve whereas the lower section lists the results of the Fourier analysis. The FFT is calculated including a maximum of 65,536 acquired

data points. Additional points at a consistent span result in a smaller frequency increment of the FFT. The number of points for the output data is half the size of that of the input data.

The upper left of the display shows information about the settings in the time range, the area between the upper and the lower window shows details about zoom and position, and the section below the large FFT display window indicates the settings (Span and Center) in the frequency range. The lower FFT display window will be outlined in white when the FFT is activated. This means that the large knob in the time range section is used to select the span. The span is specified in the unit Hz (Hertz) and identifies the width of the shown frequency range. The span position can be determined by selecting the Center value. You may use the horizontal encoder X Position for this purpose. The shown frequency range ranges from (Center - Span/2) to (Center + Span/2).

The minimum increment depends on the time base. The greater the time base, the smaller the span. Another important element for the FFT is the setting "Max. Sampling Frequency" in the ACQUIRE menu of the HMO instrument.

The soft menu key MODUS allows you to choose from the following display types:

Refresh

This mode calculates and displays the FFT without additional evaluation or editing of the captured data. The new input data is captured, displayed and overwrites previously stored and displayed values.

Envelope

In the Envelope mode, the maximum deflections of all spectra will be stored separately in addition to the current spectrum and will be updated with each new spectrum. These maximum values will be displayed with the input data and create an envelope curve. The spectrum is located within the envelope limits. This forms an area or a sleeve including all occurrences of FFT signal values. With each signal parameter change the envelope curve will be reset.

Average

This mode calculates the mean value from several spectra. It is applicable for noise reduction. The soft menu key #AVERAGES allows you to select the number of spectra used to calculate the mean value by setting the universal knob in the power of 2 from 2 to 512.

The menu entry POINTS allows you to select the maximum number of capture points to be included in the calculation by using the universal knob. The possible settings are 2048, 4096, 8192, 16384, 32768, 65536 points.

The soft menu WINDOWS allows you to improve the FFT display in case of irregularities at the margins of the mea-

surement interval. Irregularities are calculated as a leap by a computing algorithm and interfere with the measure-




Fig. 9.6: Advanced FFT menu

ment result. In the event of a bell-shaped window function, the margins with lower values are multiplied and the impact is damped. The soft menu item WINDOW allows you to choose from the following window functions:

Hanning

The Hanning window function is bell-shaped. In contrast to the Hamming window function, it is equal to zero at the margin of the measurement interval. Therefore the noise level is reduced in the spectrum and the width of the spectral lines is increased. This function is useful for a precise amplitude measurement of a period signal, for instance.

Hamming

The Hamming window function is bell-shaped. In contrast to the Hanning and Blackman window function, it is not equal to zero at the margin of the measurement interval. Therefore the height of the noise level in the spectrum is greater than with the Hanning and Blackman window function but less than with the square wave window function. However, the spectral lines not as wide as in other bell-shaped functions. This function is useful for a precise amplitude measurement of a period signal, for instance.

Blackman

The Blackman window function is bell-shaped and its waveform features the steepest fall-off among the available functions. It is zero at both ends of the measurement interval. The Blackman window function allows you to measure the amplitudes with high accuracy. However, it is more difficult to determine the frequency due to the wide spectral lines. This function is useful for a precise amplitude measurement of a period signal, for instance.

Square wave

The square wave window function multiplies all points by 1. This results in a high frequency accuracy with narrow spectral lines and increased noise. This function can be used for pulse response tests with start and end values of zero.

The menu item Y-SCALE allows you to scale the FFT in the amplitude logarithmically (dBm / dBV) or linear (V_{eff}). The unit dBm (Decibel-Milliwatt) refers to 1 mW. The unit dBV (Decibel-Volt) refers to 1 V_{eff} . The displayed values refer to a 50 Ohm terminating resistor. You can either use an internal resistor or connect an external terminating resistor parallel to the high impedance input.

Pressing the respective channel key allows you to activate a different channel as source for the FFT. You can deactivate the FFT function by pressing the soft menu key FFT OFF or pressing the FFT key on the control panel again.

9.3 Quick View

The QUICK VIEW function allows a quick overview of the typical signal size. Pressing the QUICKVIEW key (10) in the ANALYZE section of the control panel activates several basic automatic measurements. Measurement results are displayed at the bottom of the screen and with a cursor on the signal. The following five measurement values are displayed directly in the signal:

- Maximum voltage
- Mean voltage
- Minimum voltage
- Rise time
- Fall time

The following ten measurement values are displayed at the bottom of the screen:

- RMS value
- Peak to peak voltage
- Amplitude
- Pos. pulse width
- Pos. duty ratio
- Period
- Frequency
- Number of positive /slopes
- Neg. pulse width
- Neg. duty ratio

Pressing the AUTO MEASURE key allows you to change the six measurement parameters on the bottom right. You may undo these changes by choosing RESET or restore the default setting. Only one channel can be active in the Quickview mode. All measurements will be performed on the active channel.

9.4 PASS/FAIL Test Based on Masks

The Pass/Fail test allows you to evaluate if a signal is located within defined limits. This limits are set by a so-called mask. If the signal exceeds the mask, there is an error. These errors will be displayed together with successful sweeps and the total of all sweeps at the bottom of the screen. It is also possible to perform certain actions if errors are discovered.

Press the QUICKVIEW key (10) in the ANALYZE section of the control panel and press the soft menu key PASS/FAIL to activate the mode which opens a menu to set and use the mask test. Prior to starting the test by pressing the top soft menu key TEST ON/OFF, it is necessary to generate or load a mask and to select an action. To generate a new mask, press the soft menu key NEW MASK. Masks are displayed as light gray curves/waveforms on the screen. If a mask was copied or loaded, you can use menu items to

change the expansion of the signal form and consequently the limits for the test.

In the menu that opens you can use the key COPY CHANNEL to copy the current signal into a mask memory. The mask displays in white and appears as an overlay of the output signal. The menu keys Y-POSITION and STRETCH Y enable you to shift this curve vertically or to enlarge it. The two menu items WIDTH Y and WIDTH X allow you to set the tolerance for the mask. The universal knob or the KEYPAD button are used to enter values with a resolution of 1/100 division. A mask includes a minimum and a maximum value for each captured data value. The minimum and maximum value for a source curve with only one value per data are identical. The width indicates the distance between the peripheral points and the original point. The greater the selected value is, the greater are the potential curve deviations in the amplitude. The tolerance mask is displayed in white in the background. The generated and edited mask can be used immediately for the test, however, it is only saved temporarily in the instrument storage. The soft menu key SAVE can be used to store the mask permanently to a USB stick or to the internal memory. Press the key MENU OFF to return to the start menu.

Press the soft menu key LOAD MASK to open a file browser which allows you to load previously stored masks for the test (file extension .HMK). A loaded mask can be changed in the menu NEW MASK. Changes will be applied to the file when the mask is edited and saved.

Pressing the soft menu key ACTIONS in the PASS/FAIL main menu opens a menu with the available actions. The following four actions can be performed:

- Audio signal if the tolerance limits have been exceeded
- Stop for first-time failure (number is adjustable)
- Pulse for first-time failure (emits a pulse at the Y output in case of failure, only for instruments with BUS signal source)
- Screen dump for first-time failure

An action is performed if the respective condition is met (e.g. a specific number of mask failures). Each action is as-

signed a unique condition which can be defined separately from the other actions. The respective condition can be defined in the menu for the corresponding action. Select the respective action by pressing the appropriate soft menu key; the corresponding soft menu item will be highlighted in blue. Press the MENU OFF key to return to the main menu and to start the mask test.

On the right below the display window you can view the total number and the total duration of the tests (in brackets) in white. The number of successful tests and their percentage (in brackets) are displayed in green, and the number of failures and their percentage (in brackets) are displayed in red. If a test has been started, the previously unavailable soft menu key PAUSE is now activated. Pressing the PAUSE key will interrupt the test while the acquisition of signals and the total duration are continued. If you press the PAUSE key again, the test will be resumed and all event counters continue to be incremented. If you deactivate a test by pressing the soft menu key **Stop** the event and time counters will be stopped. If a new test is started by pressing the soft menu key TEST activated (Run), all counters will be reset and resume at zero.

The PASS/FAIL mode is deactivated by pressing the soft menu key PASS/FAIL OFF.




Fig. 9.7 PASS/FAIL mask test.

10 Documentation, Storage and Recall

The oscilloscope allows all screen displays that store user settings (e.g. trigger condition and time base setting), reference curves, simple curves and formula sets. An internal memory integrated with the instrument is available for reference curves, instrument settings and formula sets. These types of data, screenshots and curve data can also be stored on a connected USB stick.

The USB stick should not exceed 4 GB and must be FAT formatted (FAT32). It should be avoided to store a large number of files on the USB stick.

You can access the main menu to store and load functions by pressing the SAVE/RECALL key.

10.1 Instrument Settings

The soft menu DEVICE SETTINGS allows you to save current instrument settings load saved settings and import or export instrument settings.




Fig. 10.1: Basic menu for instrument settings

Press the soft menu key SAVE to open the Save menu. You can use the soft menu key STORAGE to select a possible location (internal memory, front or back USB connection) where you would like to save the instrument settings. Pressing this key opens the file manager. The FILE NAME can be changed or adjusted to the corresponding setting (SET

Device settings in the SCP format can be also loaded after firmware update.

is the default label). You can use the soft menu key COMMENT to enter a comment which will be displayed in the file manager footer once a file has been selected. With the soft key FORMAT and the universal knob you can choose

the HDS (binary data) or the SCP (plain text) format. In contrast to the HDS format device settings in the SCP mode can be also loaded after firmware update. Instrument settings in the HDS format from a previous firmware version cannot be loaded with a new firmware version.

The option SAVE allows you to store the settings. To reload stored preference files, press the respective soft menu key to open the soft menu LOAD. This opens the file manager where you can use the universal knob to select the respective file.




Fig. 10.2: Storing instrument settings

Once the storage location and the respective settings file has been selected, you can load the file by pressing the soft menu key LOAD. To remove files that are no longer required you can use the universal knob to select the respective settings file and remove it by pressing the soft menu key REMOVE FILE. If a USB stick is connected, you can also change and delete directories. Use the soft menu key SORT ENTRIES to sort several settings files by name, type, size or date.




Fig. 10.3: Loading instrument settings

The soft menu IMPORT/EXPORT allows you to copy a file from an internal memory to an external storage medium (USB stick) or vice versa. Source (SOURCE FILE) and target (DEST. PATH) must be selected for copying. Use the universal knob to select a storage location which will open a file manager.

Pressing the IMPORT/EXPORT key by default will copy the selected settings file. If two USB sticks are connected (front and back) this will also work between the two USB sticks. The menu item DEFAULT SETT. also allows you to load the factory default settings.

To import or export instrument settings, you must have a USB stick connected, otherwise the menu cannot be selected.

10.2 References

References are data sets which consist of settings information and A/D converter data. These may be stored and reloaded internally or externally. Data can be reloaded into one of the 4 reference memories (RE1 to RE4) which can also be displayed. The main feature of references is the fact that all information (e.g. vertical gain, time base setting, A/D converter data) is included when saving or reloading, enabling a comparison between the original signal and its corresponding values.




Fig. 10.4: Import/Export menu for instrument settings

The soft menu REFERENCES only allows you to import or export references (IMPORT/EXPORT). The transfer of references to other instruments is possible. The standard menu for the file manager opens which allows you to copy references between the internal memory and the external USB stick (description see Chap. 10.1.).




Fig. 10.5: Loading and storing references

An additional menu is opened for storing and loading references. Press the REF/BUS key in the VERTICAL section of the control panel to open a quick menu. The bottom menu key is divided into RE (reference) and BU (BUS). The current setting is highlighted in white. The soft menu key RE allows you to activate each of the four possible reference curves "RE1...RE4". This is done by pressing the respective soft menu key. The selected reference will be displayed and highlighted in the quick menu. If the reference memory is empty, a file dialog opens to load a reference curve from the internal memory.

Open the menu to store and load by pressing the MENU key in the VERTICAL section of the control panel. The top soft menu SOURCE allows you to use the universal knob to select the source for the reference to be saved. You can select from the activated channels and mathematical curves. Press the soft menu key DISPLAY to display the selected reference curve or to update the current reference curve.

To load a reference from a USB stick or the internal memory, open the soft menu LOAD. This shows a window displaying the internally stored references. You can select the desired target reference curve in the top menu item and by pressing LOAD in the file manager. To complete loading and displaying the reference, press LOAD in the file manager menu again. To save a reference, press the SAVE key, determine the source, storage location, file name and curve, and press the soft menu key SAVE (with the disk icon). The FILE NAME can be changed or adjusted to the corresponding setting (REF ist the default label). You can use the soft menu key COMMENT to enter a comment which will be displayed in the file manager footer once a file has been selected.

10.3 Curves

In addition to references, you can also store A/D converter data. A maximum of 24,000 measured samples (expanded display memory) can be stored on a USB stick. Curves can only be stored to externally connected USB sticks (not internally).

The maximum of 24,000 measured value points can only be read out with the maximum sampling rate (ACQUIRE menu). For the AUTOMATIC setting (repeat rate), the maximum amount of measured value points is limited to 6,000 (default setting).

The soft menu STORAGE allows you to use the USB connection on the front or back of the instrument as storage location. Selecting the respective storage location is possible when a USB stick has been recognized. If a USB stick is connected, you can also change, create or delete directories. Use the soft menu key SORT ENTRIES to sort several settings files by name, type, size or date. Press ACCEPT DIR. to confirm the target directory and you will automatically return to the curve main menu.

The soft menu CURVE allows you to use the universal knob to select a channel which will be saved as a curve. You may only select channels that have been activated

via channel keys. You can also save all visible channels simultaneously. The soft menu key FILE NAME opens the menu for the name entry, where you can use the universal knob to enter a name and confirm your entry by pressing ACCEPT (TRC is the default name). The curve main menu will display automatically.




Fig. 10.6: Storage menu for curves

You can open a selection window by pressing the soft menu key FORMAT to determine the file format. The universal knob allows you to select the desired format. You can choose from the following formats:

BIN:

A binary file may contain any type of Byte value. The captured curve data will be stored without any time information.

FLT

A FLT file contains the captured data as voltage values. Compared to a FLT file, the captured amount of data for a CSV file is 16 times greater. The voltage values are stored in the Float format (4 Byte Float, binary, Big Endian). This file can be reused in programs written by users, for instance.

You may only use the format CSV to store all visible channels. No other format is available.

CSV (Comma Separated Values):

In CSV files, curve data is stored in table format. Each table row is separated by a comma.

If you define the REPEAT RATE as "Max. Sampling Rate" in the ACQUIRE menu, two rows will be affixed with a time stamp during the CSV export because a minimum and a maximum value must be assigned to this time value. To acquire an amplitude value per time stamp, activate the REPEAT RATE "Automatic" in the ACQUIRE menu.

Example: Curve with all visible channels

```
[s],CH1[V],CH2[V],CH3[V],CH4[V]
-4.99500E-07,-2.601E-03,2.566E-02,-1.003E-04,1.139E-04
-4.99000E-07,-6.012E-04,-5.434E-02,-1.003E-04,-8.611E-05
-4.98500E-07,-6.012E-04,-5.434E-02,9.973E-05,-8.611E-05
-4.98000E-07,1.399E-03,-5.434E-02,2.997E-04,-8.611E-05
```

TXT

TXT files are ASCII files that only contain amplitude values (no time values). Amplitude values are separated by a comma. The value pairs are listed as single values without identification.

Example:

1.000E-02,1.000E-02,1.000E-02,1.000E-02,3.000E-02

HRT (HAMEG Reference Time)

Files with this extension are reference curves of the time domain. If the displayed curve is saved in this format, it can be used in the reference menu. The HRT format also allows you to generate files that can be reloaded into the oscilloscope via reference menu.

You can use the universal knob to select in the soft menu POINTS whether to read out the display memory or the entire acquisition memory.

Please note that the repeat rate has to be set to the maximum sampling rate via ACQUIRE key when reading out the entire acquisition memory. The entire acquisition memory can only be read out in STOP mode.

After you made all entries, press the menu key STORE to save the selected curve(s) according to the settings.

10.4 Screenshots

The most important format to store information for documentation purposes is the screenshot. A screenshot is an image file which shows the current screen content at the time that storage takes place.




Fig. 10.7: Screenshot menu

The soft menu STORAGE allows you to use the USB connection on the front or back of the instrument as storage location. Selecting the respective storage location is possible when a USB stick has been recognized. If a USB stick is connected, you can also change, create or delete directories. Use the soft menu key SORT ENTRIES to sort several settings files by name, type, size or date. Press ACCEPT DIR. to confirm the target directory and you will automatically return to the screenshot main menu.

The soft menu key FILE NAME opens the menu for the name entry where you can use the universal knob to enter a name and confirm your entry by pressing ACCEPT (SCR is the default name). The screenshot main menu will display automatically.

The file format of a graphics file determines the color depth and the type of compression. The quality of the various formats is identical for the oscilloscope graphics.

You can choose from the following file formats in the soft menu FORMAT:

- BMP = Windows Bitmap Format
- GIF = Graphics Interchange Format
- PNG = Portable Network Graphic

To achieve prints with well-defined contrasts when using the color mode INVERTED, you should set the curve intensity (via INTENS/PERSIST and universal knob) to approximately 70%.

Press the soft menu key COLOR MODE to choose from GRAYSCALE, COLOR or INVERTED with the universal knob. If GRAYSCALE is selected, the colors are converted to gray scales when the data is stored, if COLOR is selected, the data is stored as it displays in the screen, and if INVERTED is activated, data will be stored in color with a white background.

If you press the key SAVE, the current screen will be saved immediately to the selected storage location with the selected name and format.

The soft menu key PRINT allows you to print a screenshot immediately to a connected printer (e.g. PCL or PCLX as „printer language“). If a printer is detected, the soft menu key PRINT will no longer be grayed out.

Press the RUN/STOP key to stop acquisition prior to printing which will allow a correct printout.

The free software HMScreenshot (software module of the HMExplorer software) enables the transfer of screenshots in bitmap, GIF or PNG format from a HMO via RS-232 or USB interface to a connected PC where the screenshots may then be saved or printed. For additional information on the software, refer to the internal HMExplorer help at www.hameg.com.

10.5 Formula Sets

In the soft menu FORMULARIES you can import or export formula sets. This allows the data exchange between different storage media (internal memory / external USB sticks). The exact procedure is described in chapter 9.2.

10.6 FILE/PRINT Key Definition

The FILE/PRINT key in the GENERAL control panel allows you to save instrument settings, curves, screenshots and screenshot settings simultaneously with just one key. As

described in previous chapters, you must first select the corresponding settings for storage location, name etc. The soft menu key FILE/PRINT in the SAVE/RECALL main menu opens the setup menu for the FILE/PRINT key.

You may choose from the following actions:

- DEVICE SETTINGS: Stores settings
- TRACES: Stores curves
- SCREENSHOTS: Stores screenshots
- SCREEN & SETUP: Stores screenshots and settings
- PRINT: Prints directly to a compatible printer (Postscript, some PCL and PCLX capable printer)

If you press the respective soft menu key to activate the required operation, the corresponding menu will be displayed with a blue background. Press the MENU OFF key to quit the selection menu. If you press the FILE/PRINT key, the selected function will be performed.




Fig. 10.8: Definition of FILE/PRINT key

11 Mixed-Signal-Operation

As a standard, all instruments in the HMO series are equipped with the connectors for the HO3508 logic probes to add 8 or 16 digital logic inputs. All software required for the mixed signal operation is already included in the firmware of each HMO. It is only necessary to purchase and connect the active HO3508 logic probes (8 channels).

For the series HMO3004, activation of POD1 (with 8 digital inputs each) will deactivate the analog channel 3 and activation of POD2 will deactivate the analog channel 4. This allows the following configurations: 3 analog channels plus 8 logic inputs (channel 1, 2, 4 and POD1) or 2 analog channels and 16 logic inputs in mixed signal operation (channel 1, 2 plus POD1 and POD2).

11.1 Logic Trigger for Digital Input

Please find an additional description of the logic trigger for the inputs of the logic probe in chapter 6.5.

11.2 Display Functions for the Logic Channels




Fig. 11.1: Settings for the logic channel display

With the series HMO3004, you can use the short menu for channel settings to switch from an analog channel to a logic input. If channel 3 is activated and the corresponding short menu is displayed, the bottom soft menu key CH is shown in the channel color. To switch on the digital chan-

You must always set the level to indicate a High and a Low. If POD1 or POD2 are activated, press the MENU button [21] in the VERTICAL section of the control panel to display the menu. This will allow you to set the level to distinguish between the logic states. For each POD, you can activate one of five predefined logic level settings (TTL, CMOS, ECL), and two of these may be user-defined (USER 1, USER 2).

nels, press this soft menu key again which will activate PO (POD). The digital channels 0 to 7 will now display and the short menu now shows the most important settings for the digital channels. For the series HMO3002, the logic channels are activated by pressing the keys POD1 and POD2 on the front panel.

For the logic channels, a logic One will be indicated by a bar that is two pixels wide, and a logic Zero will be indicated by a bar that is one pixel wide. The set logic level and the current sample rate for the logic inputs will be shown next to the name POD1 or POD2 in the information field in the bottom left of the display.

You may now choose the Y position and the size of the logic channel display just as you would for the analog channels. Use the buttons Y-POSITION [18] and SCALE VOLTS/DIV [20] to select the settings (if the soft menu key "0/7" is selected, indicated by a blue background). If you wish to display fewer than 8 logic channels or change the position and size of a particular logic channel, you can use the short menu in combination with the soft menu keys (channel 0 to 7) and the buttons Y-POSITION [18] and SCALE VOLTS/DIV [20] to select the respective settings. You can choose a channel by pressing the ▲ and ▼ soft menu keys. This allows you to resize and position specific channels individually.

You can reset the position and size of the individual logic channels on page 2|2 of the POD menu. You also have the option to label the individual bits of the logic channel by using the soft menu NAME. The procedure to assign names is identical to the one described in chapter 4.6. The option NAME On/Off activates or deactivates the name for the individual bits D0 to D7. The name is displayed to the right of the logic channels.

You also have the option to combine digital channels to form buses which will then be displayed on the screen as a cell in a table. Basically, two independent buses are possible. For instance, it would be possible to combine an 8 bit address BUS and an 8 bit data BUS. To select the settings for the buses, press the REF/BUS button and then the MENU button in the VERTICAL section of the control panel.

In the menu that opens you can press the top soft menu key BUS to select which BUS you want to define, B1 or B2. The active BUS is indicated in blue.

You can use the soft menu key BUS TYPE to choose the BUS type for the display and the analysis. The BUS type determines the BUS structure and is organized differently depending on serial vs. parallel or the number of data and clock signals. The universal knob allows you to select the BUS type PARALLEL or PARALLEL + CLK. Select CONFIGURATION to determine the BUS source and structure. The contents of the menu change with the selected BUS type. After pressing the top soft menu key BUS WIDTH,

you can use the universal knob to select a BUS width from 1-16 bits. The table displaying the bit assignments will be adjusted dynamically depending on your choice. Each bit of the displayed BUS has a source. The source refers to the individual POD bits. Based on the measurement setup, the sources can be assigned via soft menu key SOURCE and the universal knob. The soft menu keys PREVIOUS/NEXT BIT allow you to move the position of the selection bar for the source of the individual bits. The selected bit is highlighted in blue. The left side of the table contains the bits in fixed sequence, beginning at the top with D0 (= LSB). The universal knob allows you to assign a real logic channel to the selected BUS bit. For instance, the logic channel D9 is assigned to BUS bit D0 (this corresponds to the LC9 input for POD2). The allocation is not subject to restrictions; you can also use partially identical logic channels in the two possible buses.

If you select PARALLEL + CLOCK as BUS TYPE, you can also use the bottom soft menu key CONTROL WIRES to select sources for CHIP SELECT, and you can use the universal knob to select the settings for CLOCK. The soft menu key ACTIVE is used to determine if the chip select signal High or Low Active is selected.

The soft menu key SLOPE allows you to toggle between rising, falling and both slopes. The active selection is always highlighted in blue and is listed after the label CLK in the bit source window. Press the MENU OFF button to return to the BUS main menu.

The soft menu DISPLAY SETUP opens a menu to select the display format and its extent. The universal knob in the submenu allows you to choose the format to decode the BUS values. You can choose from the following formats:

- Binary
- Hexadecimal
- Decimal
- ASCII

The decoded values will be shown in the cells/tables of the buses according to the selected format. The next soft menu key BITS can also be used to activate or deactivate the table display for the individual BUS bits.

A white dot in the short menu indicates that a BUS is activated. You can now use the position control knob to determine the position of the BUS display on the screen. The VOLT/DIV knob allows you to determine the size of the table display. This may be particularly useful for the binary display as it allows the display of the complete value in up to 4 rows even for short tables.

11.3 Cursor Measurements for Logic Channels

If the logic channels are activated, you may select several parameters via cursor measurements (CURSOR MEASURE button). For all activated logic channels of a POD, you can choose from the measurement types TIME, RATIO X and

V-MARKER. The results for the logic channels will be as follows:

TIME

The display will include the time position of both cursors relative to the trigger time, the time difference between the two positions and the resulting frequency.

RATIO X

In this measurement type, three cursors are used to display a time ratio between the first two cursors plus the first and third cursor. The results are shown in floating point format, in percent, in degrees and in radians.

V-MARKER

For the logic channels, the logic value of the selected POD will be measured at the respective cursor and shown in hexadecimal and decimal format.

11.4. Automatic Measurements for Logic Channels

If the logic channels are activated, you can use the automatic measurement functions to determine several parameters. For all activated logic channels of a POD, you can choose from the measurement types FREQUENCY, PERIOD, PULSE WIDTH +/-, DUTY CYCLE+/-, DEALY, PHASE, BURST WIDTH, NUMBER PULSE +/- and NUMBER SLOPE pos./neg. As with all automatic measurements, you can activate the statistic on page 2|2.

12 Serial BUS analysis

12.1 The options HOO10, HOO11 and HOO12

The HMO series can be equipped with three options to trigger and decode serial buses.

The option HOO10 can be used to trigger and decode I²C, SPI and UART/RS-232 buses on the digital channels (option logic probe HO3508) and on the analog inputs. This option allows the decoding of two serial buses simultaneously.

The option HOO11 can be used to trigger and decode I²C, SPI and UART/RS-232 buses on analog inputs only and it only allows the decoding of one serial BUS at a time.

The option HOO12 can be used to trigger and decode CAN and LIN buses on the digital channels (option logic probe HO3508) and on the analog inputs. This option allows the decoding of two serial buses simultaneously.

The options are activated by a software licence key. This key will either be installed at the time of manufacturing or it will be loaded to the instrument via USB stick when the user installs an update as described in chapter 2.10

The analysis of parallel and serial data consists of the following three basic steps:

- **Protocol configuration**
(BUS type / protocol-specific settings)
- **Decoding**
(Display of decoded data / Zoom / BUS table)
- **Trigger**
(Start / Stop / serial samples)

The serial BUS analysis is performed with 1/8 of the sampling rate.

12.2 Serial Bus Configuration

Prior to the BUS configuration it is necessary to set the correct logic level for the digital channels (see chapter 11.2 or the analog channels (see chapter 4.5. The default setting for both is 500 mV.

Make sure that a complete message of a serial protocol is always displayed on the screen to ensure decoding can function properly. The Zoom function allows you to view details for any specific message.

It is necessary to define a BUS before you can determine the settings for the serial trigger and decoding functions. A maximum of two buses, B1 and B2, may be defined. Press the BUS/REF button in the VERTICAL section of the control panel. This will open a short menu where you can press the bottom soft menu key BU (BUS). Use the MENU button in

the VERTICAL section of the control panel and the top soft menu key to define the respective BUS (B1 or B2).

Use the soft menu key BUS TYPE and the installed options HOO10/HOO11/HOO12 to choose from the following BUS types:

■ Parallel	Standard
■ Parallel + Clock	Standard
■ SSPI (2 wire)	HOO10/HOO11
■ SPI (3 wire)	HOO10/HOO11
■ I ² C	HOO10/HOO11
■ UART	HOO10/HOO11
■ CAN	HOO12
■ LIN	HOO12




Fig. 12.1: Menu for the definition of buses

The soft menu key CONFIGURATION allows you to invoke a menu corresponding to the selected BUS type. A menu description can be found in the chapters of the respective BUS configuration. The soft menu DISPLAY SETUP is identical for all buses and allows you to select the decoding format.

You may choose from the following formats: Binary, Hexadecimal, Decimal and ASCII




Fig. 12.2: Decoding format selection menu

Use the soft menu key BITS to activate or deactivate the display of individual bit lines (above the table display). The

soft menu key NAME allows you to rename a BUS (see chapter 4.6)

12.2.1 BUS Table

The soft menu BUS TABLE allows you to configure / export a list of all decoded messages in storage. The table content is protocol specific and the table display can be activated for each individual BUS type. The top soft menu




Fig. 12.3: Example I²C BUS with BUS table

key BUS TABLE allows you to activate or deactivate the list view. By default, the table is displayed at the bottom of the screen. Generally, a complete message of a protocol is displayed in a row. The columns include important information, e.g. address and date of the message. The number of rows in the table is identical to the number of complete message frames in storage. The decoding results may be saved as CSV file by using the soft menu key SAVE (e.g. save to a USB stick).

Example of a I²C BUS table:

"Bus table: BUS1 (I²C: Clock SCL = D0, Dates SDA = D1)"
 Frame,Mark,Start time[s],Type,ID,Length,Date,Condition
 1,,-197.89200e-6,Read,0x2D,5,0xF110E55D31,OK
 2,,28.00000e-9,Write,0x42,8,0xEB8DC599AE5D6FC0,OK
 3,,217.74000e-6,Write,0x3B,6,0xA113B7263E5B,OK
 4,,376.07200e-6,Read,0x0E,6,0x55C3EB71D9E8,OK
 5,,613.58000e-6,Write,0x66,8,0x91B86EE6655E2300,Data Error0

A BUS table can only be stored if the STOP mode is active.

The soft menu key TRACK FRAME allows you to scroll through the BUS table and simultaneously jump to the corresponding position in the memory via universal knob to display details on the screen. However, this is only possible if acquisition has been stopped. This option is also available in the short menu BUS via soft menu key Trk (= Track). If you activate the soft menu key FRAME TIME DIFFERENCE (highlighted in blue), the time difference to the previous frame (data packet) will be displayed in the BUS table. This column will be labeled in the table as "Time diff. ". If this function is deactivated, the absolute time in

relation to the trigger point will be displayed in the column "Start time". The soft menu key Tab in the BUS short menu allows you to activate or deactivate the BUS table without opening a menu.

12.3 Parallel BUS

The HMO series is able to analyze up to 15 bit lines (depending on activated POD1/POD2). The soft menu key BUS WIDTH and the universal knob allow you to select the number of bit lines. You can use the soft menu keys PREV. BIT and NEXT BIT (or the universal knob) to move the position of the SOURCE selection bar for individual BUS bits. The selected bit is highlighted in blue. To trigger on parallel buses, it is recommended to use the logic trigger (see chapter 6.5).

12.4 I²C BUS

The I²C BUS is a two-wire BUS which was developed by Philips (today known as NXP Semiconductor). The HMO series supports the following bit rates (for measurements without measuring object via BUS SIGNAL SOURCE):

- 100 kBit/s (Standard Mode)
- 400 kBit/s (Fast Mode)
- 1000 kBit/s (Fast Mode Plus).

Use the soft menu PROBE COMP & BUS SIGNAL SOURCE to select the respective clock rate in the SETUP menu (page 2|2).




Fig. 12.4: I²C BUS signal source

A I²C BUS has the following properties:

- **Two wire BUS (2-wire):** Clock (SCL) and data (SDA)
- **Master-Slave Communication:** the master provides the clock pulse and selects the slave
- **Addressing:** Each slave can be addressed via unique address; multiple slaves can be linked with each other and can be addressed by the same master
- **Read/Write bit:** Master reads data (=1) or writes data (=0)
- **Acknowledge:** issued after each byte

The format of a simple I²C message (frame) with an address length of 7 bit is structured as follows:

- **Start condition:** Falling slope on SDA (Serial Data), while SCL (Serial Clock) is HIGH

- **7 bit address:** write or read slave
- **Read/Write bit (R/W):** Indicates, if the data is to be written or read out from the slave
- **Acknowledge bit (ACK):** Is issued by the recipient of the previous byte if transmission was successful (exception: for read access, the master terminates the data transmission with a NACK bit after the last byte)
- **Data:** a series of data bytes with a ACK bit after each byte
- **Stop condition:** rising slope on SDA (Serial Data), while SCL (Serial Clock) is HIGH




Fig. 12.5: I2C 7 bit address

12.4.1 I2C BUS Configuration

Prior to the BUS configuration it is necessary to set the correct logic level for the digital channels (see chapter 11.2 or the analog channels (see chapter 4.5. The default setting for both is 500 mV.

Make sure that a complete message of a serial protocol is always displayed on the screen to ensure decoding can function properly. The Zoom function allows you to view details for any specific message.




Fig. 12.6: Menu for the definition of I2C sources

To decode the I2C BUS it is necessary to determine during the BUS configuration which logic channel will be connected to the clock and which one to the data line. This setting is selected after choosing the BUS TYPE I2C in the BUS menu and pressing the soft menu key CONFIGURATION. In the menu, choose the top soft menu key CLOCK SCL and use the universal knob to select the source chan-

If the option H0011 is installed, it is only possible to select analog channels as source. If the option H0010 is installed, both analog and digital channels are available as source.




Fig. 12.7: I2C message decoded with hexadecimal values

nel. You can define the data channel by pressing the soft menu key DATA SDA. A small window provides information about the current settings.

Press the MENU OFF button twice to close all menus. Certain portions of the I2C messages will be displayed in color to distinguish between the different elements. If the data lines are selected with the table display, the respective sections will also be displayed in color. These are described as follows:

- Read address: Yellow
- Write address: Magenta
- Data: Cyan
- Start: White
- Stop: White
- No acknowledge: Red
- Acknowledge: Green

The decoding of the address is performed as a 7 bit value. The 8th bit for the write/read distinction will be decoded in color, not in the HEX value of the address.

12.4.2 I2C BUS Triggering

After the BUS configuration, it will be possible to trigger on various events. Press the TYPE button in the TRIGGER section of the control panel and choose the soft menu key




Fig. 12.8: I2C READ/WRITE trigger menu

SERIAL BUSES. Then press the SOURCE button in the TRIGGER section and choose I²C BUS. This will only be available if it was configured earlier. Press the FILTER button in the TRIGGER section of the control panel to list all available I²C trigger conditions.

You can trigger on the START signal (the start signal is the falling slope on SDA when SCL is high), and the STOP signal (the start signal is the rising slope on SDA when SCL is high) of all messages as well as on a RESTART (the new start signal is a repeated start signal) or on a NOT-ACKNOWLEDGE condition. The NOT-ACKNOWLEDGE bit is the 9th bit in a data or address unit of the SDA line. For NOT-ACKNOWLEDGE, the Acknowledge bit is on SDA high, although it should be low.




Fig. 12.9: I²C data trigger menu

The soft menu key READ/WRITE offers additional trigger options. You can use the soft menu key MASTER to toggle the trigger condition between read and write access. The 8th bit of the first data unit (depending on the address length) is used to distinguish between read and write access. The selected condition is displayed in the I²C settings window and is highlighted by the menu key in blue.

The address length (in bit) defines the maximum number of slave addresses to be used with the BUS. For a 7 bit address length, the maximum number of available addresses is 112. The 10 bit addressing mode is downward

compatible with the 7 bit addressing mode by using 4 of 16 reserved addresses and can be used simultaneously. For a 10 bit address length, a total of 1136 addresses (1024 + 128 - 16) is available. The highest 10 bit address is 1023 (0x3FF). The selected address length is displayed in the I²C settings window and is highlighted by the menu key in blue.

The SLAVE ADDRESS is the address used on the BUS to distinguish which slave the master communicates with. Use the universal knob to select the address for the observing BUS participant to be triggered.

The soft menu DATA enables you to enter specific data in addition to the address. With this menu, you can trigger on clearly defined data bytes (color cyan) within the transmission, allowing you to filter out irrelevant transmissions.

You can trigger on up to 24 bit (3 byte) of data. An offset of 0 to 4095 to the address is allowed. Select BYTE OFFSET which defines the distance between the bytes relevant for the trigger condition and the address. In most cases, the byte offset is zero if the trigger is to occur on the maximum first 24 bits after the address. The soft menu key NUMBER OF BYTES allows you to define how many bytes are to be analyzed for the trigger condition. The input may be binary or hexadecimal (PATTERN INPUT). If binary input is selected, the individual bits can be assigned to any condition via soft menu key SELECT BIT and the universal knob. The soft menu key STATE allows you to set the state H (=1), L (=0) or X (don't care) for each bit. The state X defines any state. If the input is hexadecimal, only the entire byte can be set to X.

If you choose the hexadecimal input, use the soft menu key VALUE and the universal knob to set the respective byte value. The soft menu key SELECT BYTE allows you to edit the different bytes (byte 1 to byte 2 to byte 3 etc.) sequentially (depending on the defined NUMBER OF BYTES). The active byte will be marked with a green border in the display window of the trigger condition (see fig. 12.9). Press the MENU OFF button three times to close all menus, and the oscilloscope will trigger on the set address and data.

12.5 SPI / SSPI BUS

The Serial Peripheral Interface SPI is used to communicate with slow peripheral devices, in particular for the transfer of data streams. The SPI BUS was developed by Motorola (today known as Freescale); however, it has not been formally standardized. Generally, this is a BUS with clock and data lines and a select line (3-wire). If only one master and one slave are present, the select line may be deleted. This type of line is also called SSPI (Simple SPI) (2-wire).

The HMO series supports the following bit rates (for measurements without measuring object via BUS SIGNAL SOURCE):

- 100 kBit/s,
- 250 kBit/s und
- 1 MBit/s.




Fig. 12.10: Example I²C BUS with BUS table




Fig. 12.11: SPI BUS signal source

Use the soft menu PROBE COMP & BUS SIGNAL SOURCE to select the respective clock rate in the SETUP menu (page 2|2). A SPI BUS has the following properties:

- Master-slave communication
- No instrument addressing
- No acknowledge to confirm data reception
- Duplex capability

Most SPI buses have 4 common lines, 2 data lines and 2 control lines:

- Clock to all slaves (SCLK)
- Slave select or chip select lines (SS or CS)
- Master-Out-Slave-In, Slave-Data-Input (MOSI or SDI)
- Master-In-Slave-Out, Slave-Data-Output (MISO or SDO)

If the master generates a clock pulse and selects a slave, data can be transmitted in either one direction or simultaneously in both directions.




Fig. 12.12: Simple configuration of a SPI BUS

12.5.1 SPI / SSPI BUS Configuration

Prior to the BUS configuration it is necessary to set the correct logic level for the digital channels (see chapter 11.2, or the analog channels (see chapter 4.5). The default setting for both is 500 mV. For the two channel instruments, the CS (chip select) must be connected to the external trigger input; the level can be set at the setup menu of the BUS under CONFIGURATION > EXTERNAL LEVEL.

Make sure that a complete message of a serial protocol is always displayed on the screen to ensure decoding can function properly. The Zoom function allows you to view details for any specific message.

Certain settings are necessary to guarantee that a SPI BUS is decoded correctly. First, you have to determine if a SPI system with or without chip select is available (2-wire or

3-wire SPI). This can be done in the BUS setup menu when selecting the BUS type. For a 2-wire SPI system, select the option SSPI; for a 3-wire SPI system, select the option SPI. Then press the CONFIGURATION button to open the setup menu for SPI.




Fig. 12.13: Menu for the definition of a SPI BUS

Use the top soft menu key SOURCE to select the respective channel for chip select (CS), clock (Clk) and data. Select the respective soft menu key CS, Clk or Data (key will be highlighted in blue) and then use the soft menu key DATA and the universal knob to select the respective source channel. For the 2-wire SPI, select the possible TIME OUT instead of a chip select source. During the time out, data and clock line are at Low. When the time out has been reached, a new frame begins. If the time intervals between the data packets are shorter than the time out, these packets belong to the same frame. You can select the dead time via universal knob or via numeric input (KEYPAD button). A small window provides information about the current settings (see fig. 12.13).

If the option H0010 is installed, it is possible to select analog and digital channels as source. For the installed option H0011, only the analog channels are available as source. For two channel instruments and a 3-wire SPI, the chip select signal has to be connected to the external trigger input.

In addition to assigning the source, the soft menu key ACTIVE allows you to select the following settings:

- CS: Chip select high or low active (low active is the default setting)
- CLK: Data will be stored with rising or falling slope (rising slope is the default setting)
- DATA: Data high or low active (high active is the default setting)

You can use the soft menu key BIT ORDER to determine if the data of each message starts with the MSB (most significant bit) or the LSB (least significant bit). The soft menu key WORD SIZE allows you to select via universal knob how many bits are included per message. You may select any value between 1 and 32 bits.

12.5.2 SPI / SSPI BUS Triggering

After the BUS configuration, it will be possible to trigger on various events. Press the TYPE button in the TRIGGER section of the control panel and choose the soft menu




Fig. 12.14: SPI trigger menu

key SERIAL BUSES. Then press the SOURCE button in the TRIGGER section and choose SPI Bus. This will only be available if it was configured earlier. Press the FILTER button in the TRIGGER section of the control panel to list all available SPI trigger conditions.

The option FRAME START sets the trigger event on the start of the frame. The frame starts when the chip select (CS) signal switches to the selected active mode. By contrast, FRAME ENDE sets the trigger event on the end of the frame. The frame ends when the chip select (CS) signal switches from the selected active to the inactive mode. The soft menu key BIT and the universal knob allow you to select the trigger time to the set bit within the set bit sequence. You can also enter a numeric value to determine the desired bit number (KEYPAD button).

Use the soft menu SER. PATTERN to define a specific bit sequence within the frame which start the trigger event. The soft menu key BIT OFFSET allows you to select the first bit of the predefined bit sequence within the frame. The bits in front of it have no impact on the trigger event (for instance, if the bit offset = 2, bit 0 and bit 1 after CS will be ignored and the pattern begins with bit 2). You can select a value between 0 and 4095 via universal knob or enter it numerically (KEYPAD button). The soft menu key NUMBER OF BITS allows you to select how many bits will be analyzed for the trigger condition. You can select a value between 1 and 32 bit via universal knob. The serial bit sequence (PATTERN INPUT) can be entered as binary or hexadecimal value.

If you choose the binary input, the soft menu key SELECT BIT and the universal knob allow you to select which individual bits within the data are to be edited. The option STATE allows you to assign a logic state to each bit (High = H = 1, Low = L = 0 or X = don't care). The state X de-

fines any state. If you choose the hexadecimal input, the soft menu key VALUE and the universal knob allow you to set the value for the respective nibble (4 bit). If the input is hexadecimal, only the entire nibble can be set to X. Use the soft menu key SELECT NIBBLE to toggle between nibbles. The active nibble will be marked with a green border in the display window of the trigger condition (see fig. 12.15). Press the MENU OFF button three times to close all menus, and the oscilloscope will trigger on the set bit sequence.




Fig. 12.15: SPI data trigger menu

12.6 UART/RS-232 BUS

The UART (Universal Asynchronous Receiver Transmitter) BUS is a general BUS system and the base for many protocols. One example is the RS-232 protocol. It consists of a frame with a start bit, 5 to 9 data bits, one parity bit and a stop bit. The stop bit can assume the single length, or 1.5 or twice the length of a normal bit.




Fig. 12.16: UART bit sequence

The HMO series supports bit rates of 9600 bit/s, 115.2 kBit/s and 1 MBit/s (for measurements without measuring object via BUS SIGNAL SOURCE). Use the soft menu PROBE COMP & BUS SIGNAL SOURCE to select the respective clock rate in the SETUP menu (page 2|2).

12.6.1 UART/RS-232 BUS Konfiguration

Prior to the BUS configuration it is necessary to set the correct logic level for the digital channels (see chapter 11.2 or the analog channels (see chapter 4.5. The default setting for both is 500 mV.

Make sure that a complete message of a serial protocol is always displayed on the screen to ensure decoding can function properly. The Zoom function allows you to view details for any specific message.

To decode the UART BUS it is necessary to first determine which channel will be connected to the data line. This setting is selected after choosing the BUS type UART in the BUS menu and pressing the soft menu key CONFIGURA-




Fig. 12.17: Page 1 of the menu to define a UART BUS

TION. In the menu that opens you can press the top soft menu key DATA SOURCE to select the desired channel via universal knob. If the option HOO10 is installed, each analog and digital channel is available as source. If the option HOO11 is installed, it is only possible to select analog channels as source.

The soft menu key ACTIVE can be used to determine if the data transferred to the BUS are active high (High = 1) or active low (Low = 1) (for RS-232, choose Low). Use the soft menu key SYMBOL SIZE and the universal knob to select a value between 5 bit to 9 bit for the bits that form a symbol. Another setting can be selected via soft menu key PARITY. Parity bits are used to detect errors during a transmission.

The soft menu PARITY offers the following options:

- **None:** Use no parity bits
- **Even:** The parity bit is set to "1" if the number of ones in a specific set of bits is uneven (without parity bit)
- **Odd:** The parity bit is set to "1" if the number of ones in a specific set of bits is even (without parity bit)

The bottom soft menu key STOP BITS allows you to define the length of the stop bit (1 = single, 1.5 = 1 1/2 or 2 = double).




Fig. 12.18: Page 2/2 UART BUS setup menu

On page 2/2 of the UART BUS setup menu, you can select the BIT RATE (symbol rate) via universal knob. The bit rate defines how many bits are sent per second. The soft menu key BIT RATE allows you to select standard numeric values. Press the soft menu key USER if you wish to define customized rates via universal knob or numeric input (KEY-PAD button).

The IDLE TIME describes the minimum time between the stop bit of the last data and the start bit of the new data. The sole purpose of the idle time is to define the start of a transmission and consequently the exact start of a frame (one or more symbols, most commonly bytes). Only this information can guarantee correct decoding and triggering (regardless of the trigger type). A start bit within the idle time will not be recognized. You can enter the value via universal knob or numeric input (KEYPAD button).

12.6.2 UART/RS-232 BUS Triggering

After the BUS configuration, it will be possible to trigger on various events. Press the TYPE button in the TRIGGER section of the control panel and choose the soft menu key SERIAL BUSES. Then press the SOURCE button in the TRIGGER section and choose UART. This will only be available if it was configured earlier. Press the FILTER button in the TRIGGER section of the control panel to list all available UART trigger conditions.




Fig. 12.19: Trigger menu UART data

The trigger condition START BIT sets the start bit as trigger event. The start bit is the first 0 bit that succeeds a stop bit or idle time. The soft menu key FRAME START defines the first start bit after idle time. The soft menu key SYMBOL<N> assigns a predefined N-th symbol as trigger event. The soft menu ANY SYMBOL allows you to define any symbol to trigger on. The symbol can be located anywhere within a frame. The serial bit sequence (PATTERN INPUT) can be entered as binary or hexadecimal value. If you choose the binary input, the soft menu key SELECT BIT and the universal knob allow you to select which individual bits within the data are to be edited. Select the option STATE to assign a logic state to each bit (High = H = 1, Low = L = 0 or X = don't care). The state X defines any state. If you choose the hexadecimal input, the soft menu

key VALUE and the universal knob allow you to set the value for the respective symbol. If the input is hexadecimal, only the entire symbol can be set to X. Use the soft menu key SELECT SYMBOL to toggle between symbols.




Fig. 12.20: UART trigger menu page 2

The soft menu PATTERN offers additional options for UART trigger settings. The soft menu key SYMBOL OFF-SET and the universal knob are used to select the number of irrelevant symbols that proceed the pattern within the frame that are relevant for the trigger event. Any value between 0 to 4095 symbols after the start bit may be entered. Use the soft menu key NUMB. OF SYMB. to select the number of relevant symbols as 1, 2 or 3. The number of symbol defines the pattern size. The symbol length (5 to 9 bit) was configured at the time of the BUS definition and will be observed accordingly in the trigger menu.

The value input for the symbols may be binary or hexadecimal (as described above). Use the soft menu key PATTERN INPUT for this selection. If binary input is selected, the individual bits can be assigned via soft menu key SELECT BIT and the universal knob. The soft menu key STATE allows you to determine the state for each bit (1, 0 or X). If you choose the hexadecimal input, the soft menu key VALUE and the universal knob allow you to set the value for the respective symbol. Use the soft menu key SELECT SYMBOL to toggle between symbols. The active byte will be marked with a green border in the display window of the trigger condition. Press the MENU OFF button twice to close all menus, and the oscilloscope will trigger on the set data.

Use the respective soft menu key on page 2|2 of the UART trigger filter menu to select a PARITY ERROR (trigger with a parity filter), a FRAME ERROR (trigger with a frame error) or a BREAK (trigger with a break) as the desired trigger condition. The BREAK condition is fulfilled if a stop bit does not succeed a start bit within a specified time period. The stop bits low are active during the break.

12.7 CAN BUS

The CAN (Controller Area Network) BUS is a BUS system primarily developed for automotive applications and is used for the data exchange between controller units and sensors. It can be found increasingly in the aviation, healthcare, and general automation industries. At the physical level, CAN is a differential signal, therefore a differential probe (e.g. HZO40) is recommended for decoding, although standard probes are equally suitable to capture the signals. The standard data rates range between 10 kBit/s and 1 MBit/s. A CAN message primarily consists of a start bit, the Frame ID (11 or 29 bit), the data length code DLC, the data, a CRC, acknowledge and an end bit.

12.7.1 CAN BUS Configuration

To decode the CAN BUS it is necessary to first determine which channel will be connected to the data line. This setting is selected after choosing the BUS type CAN in the BUS menu and pressing the soft menu key CONFIGURATION. In the menu that opens you can press the top soft menu key DATA to select the desired channel via universal knob. An analog or a digital channel can be connected to CAN-High or CAN-Low. In addition, it is possible to connect a differential probe (e.g. HZO40) to an analog channel. When using a differential probe, select CAN High if the positive input of the probe is connected to CAN-H and the negative input to CAN L. If the probe is connected with reversed polarity, you must select CAN L.

The soft menu key SAMPLE POINT allows you to specify the exact point within the bit at which the value for the current bit is sampled. You can select a value in percent (25% to 90%) via universal knob. The option BIT RATE defines how many bits are transmitted per second and allows you to select default data rates (10 / 20 / 33.333 / 50 / 83.333 / 100 / 125 / 250 / 500 kBit/s and 1 MBit/s) via universal knob. Use the soft menu key USER to specify user-defined bit rates. You can enter the value via universal knob or numeric input (KEYPAD button).

12.7.2 CAN BUS Triggering

After the BUS configuration, it will be possible to trigger on various events. Press the TYPE button in the TRIGGER section of the control panel and choose the soft menu key SERIAL BUSES. Then press the SOURCE button in the TRIGGER section and choose CAN. This will only be available if it was configured earlier. Press the FILTER button in the TRIGGER section of the control panel to list all available CAN trigger conditions.

The function START OF FRAME triggers on the first slope of the SOF bit (synchronizing bit). The function END OF FRAME triggers on the end of the frame. The soft menu FRAME offers the following options:

- **ERROR:** General frame error
- **OVERLOAD:** Trigger on CAN Overload frames
- **DATA:** Trigger on data frames; select the correct identifier type via universal knob

- **READ DATA:** Trigger on read frames; select the correct identifier type via universal knob
- **DATA|READ:** Trigger on read and data frames; select the correct identifier type via universal knob
- **ID TYPE:** Identifier type (11 bit, 29 bit or any)

The soft menu ERROR identifies various errors in a frame. This menu allows you to choose one or several error message types as trigger condition:

STUFF BIT

Individual frame segments (e.g. frame start etc.) are coded during the bit stuffing procedure. The transmitter automatically adds a complimentary bit to the bit stream if it detects 5 consecutive bits with identical value in the

Prior to the BUS configuration it is necessary to set the correct logic level for the digital channels (see chapter 11.2 or the analog channels (see chapter 4.5. The default setting for both is 500 mV.

Make sure that a complete message of a serial protocol is always displayed on the screen to ensure decoding can function properly. The Zoom function allows you to view details for any specific message.

bit stream to be transmitted. A “stuff” error occurs if the 6th identical bit level is detected in the specified sections.

FORM

A form error occurs if a fixed bit field contains one or several invalid bits.

ACKNOWLEDGE

An authentication error occurs if the transmitter receives no authentication (acknowledge).

CRC (Cyclic Redundancy Check)

CAN BUS applies a complex checksum calculation (Cyclic Redundancy Check). The transmitter calculates the CRC and transmits the result in a CRC sequence. The receiver calculates the CRC in the same manner. A CRC error occurs if the calculated result deviates from the received CRC sequence.




Fig. 12.21: Setting the SAMPLE POINT during the CAN configuration

The soft menu key IDENTIFIER identifies the priority and the logical address of a message. In the menu that opens you can press the top soft menu key to select the FRAME TYPE (general data, read data or read/write data) via universal knob. The soft menu IDENTIFIER SETUP below allows you to specify the length of the identifier type via soft menu key ID TYPE and universal knob (11 bit base or 29 bits for extended CAN frames). The soft menu key COMPARE defines the comparison function. If the pattern includes at least one X (don't care), it is possible to trigger on a value equal or not equal to the specified value. If the pattern includes only 0 or 1, it is possible to trigger on an area greater than or less than the specified value. The PATTERN INPUT may be binary or hexadecimal. If you choose the binary input, the soft menu key BIT and the universal knob allow you to select which individual bits within the data are to be edited.




Fig. 12.22: CAN data trigger menu

Select the option STATE to assign a logic state to each bit (High = H = 1, Low = L = 0 or X = don't care). The state X defines any state. If you choose the hexadecimal input, the soft menu key VALUE and the universal knob allow you to set the value for the respective byte. If the input is hexadecimal, only the entire byte can be set to X. Use the soft menu key BYTE to toggle between bytes.

The soft menu IDENTIFIER AND DATA includes the same settings as the soft menu IDENTIFIER. In the menu that opens you can select the FRAME TYPE (general data or read data) via top soft menu key and universal knob. In the menu IDENTIFIER SETUP below you can enter the address of the respective pattern. The soft menu DATA SETUP allows you to specify the data bit pattern or HEX values for up to 8 bytes (only available if DATA was selected as frame type). Available comparisons for address and data values are GREATER, EQUAL OR LESS, EQUAL and NOT EQUAL.

Press the MENU OFF button twice or three times to close all menus, and the oscilloscope will trigger on the set data.

12.8 LIN BUS

The LIN (Local Interconnect Network) BUS is a simple master/slave BUS system for automotive applications and is used for the data exchange between controller units and sensors or actuators. The signal is transmitted on one line with ground reference to the vehicle mass. The standard data rates range between 1.2 kBit/s and 19.2 kBit/s. A LIN message consists of a header and the data.

A LIN BUS has the following properties:

- Serial single-wire communication protocol (byte-oriented)
- Master-slave communication (generally up to 12 knots)
- Master-controlled communication (master initiates / coordinates communication)




Fig. 12.23: Layout LIN byte structure

The data is transmitted in bytes without parity (based on UART). Each byte consists of a start bit, 8 data bits and a stop bit.

12.8.1 LIN BUS Configuration

Prior to the BUS configuration it is necessary to set the correct logic level for the digital channels (see chapter 11.2 or the analog channels (see chapter 4.5. The default setting for both is 500 mV.

Make sure that a complete message of a serial protocol is always displayed on the screen to ensure decoding can function properly. The Zoom function allows you to view details for any specific message.

To decode the LIN BUS it is necessary to first determine which channel will be connected to the data line. This setting is selected after choosing the BUS type LIN in the BUS menu and pressing the soft menu key CONFIGURATION. In the menu that opens you can press the top soft menu key DATA to select the desired channel via universal knob. The soft menu key POLARITY allows you to toggle between High and Low; the active function will be highlighted in blue.

If LIN standard VERSION J2602 is selected, you may only choose from the predefined standard data rates via bottom menu item and universal knob.

An analog or a digital channel can be connected to LIN-High or LIN-Low. You can select any version for the LIN standard (version 1x, version 2x, J2602 or any) via soft menu key VERSION and universal knob. The option BIT RATE allows you to specify the number of transmitted bits per second. You can use the universal knob to choose from predefined standard data rates (1.2 / 2.4 / 4.8 / 9.6 / 10.417 and 19.2 KBit/s) and user-defined data rates (USER). The highest possible user-defined data rate is 4 MBit/s.

You can enter the user-defined value via universal knob or numeric input (KEYPAD button).

12.8.2 LIN BUS Triggering

After the BUS configuration, it will be possible to trigger on various events. Press the TYPE button in the TRIGGER section of the control panel and choose the soft menu key SERIAL BUSES. Then press the SOURCE button in the TRIGGER section and choose LIN. This will only be available if it was configured earlier. Press the FILTER button in the TRIGGER section of the control panel to list all available CAN trigger conditions.

The function START OF FRAME triggers on the stop bit of the synchronizing field. The function WAKE UP triggers after a wake-up frame. The soft menu ERROR identifies various errors in a frame. This menu allows you to choose one or several error message types as trigger condition:

CRC (Cyclic Redundancy Check)

LIN BUS applies a complex checksum calculation (Cyclic Redundancy Check). The transmitter calculates the CRC and transmits the result in a CRC sequence. The receiver calculates the CRC in the same manner. A CRC error occurs if the calculated result deviates from the received CRC sequence.

PARITY

Triggering occurs on a parity error. Parity bits are bit 6 and bit 7 of the identifier. The correct transfer of the identifier is verified.

SYNCHRONISATION

Triggering occurs if the synchronizing field indicates an error.

With the soft menu key IDENTIFIER you can set the trigger to a specific identifier or a specific identifier range. The soft menu key COMPARE defines the comparison function. If the pattern includes at least one X (don't care), it is possible to trigger on a value equal or not equal to the specified value. If the pattern includes only 0 or 1, it is possible to trigger on an area greater than or less than the specified




Fig. 12.24: Menu for the definition of a LIN BUS

value. The PATTERN INPUT may be binary or hexadecimal. If you choose the binary input, the soft menu key BIT and the universal knob allow you to select which individual bits within the data are to be edited. Select the option STATE to assign a logic state to each bit (High = H = 1, Low = L = 0 or X = don't care). The state X defines any state. If you choose the hexadecimal input, the soft menu key VALUE and the universal knob allow you to set the value for the respective byte. If the input is hexadecimal, only the entire byte can be set to X. Use the soft menu key BYTE to toggle between bytes.

The soft menu IDENTIFIER AND DATA and the soft menu key IDENTIFIER SETUP include the same settings as the soft menu IDENTIFIER. The soft menu DATA SETUP allows you to specify the data bit pattern or HEX values for up to 8 bytes. Available comparisons for address and data values are EQUAL and NOT EQUAL.

Press the MENU OFF button twice or three times to close all menus, and the oscilloscope will trigger on the set data.




Fig. 12.25: LIN data trigger menu

13 Remote control

The HMO series is equipped with the interface card HO730, which have an Ethernet and USB connection on board as a standard.

To make any communication possible, the chosen interface and it's corresponding settings must be the same in the PC as in the oscilloscope. Only exception is the virtual COM port, which is described under the USB section.

13.1 Ethernet

In addition to the USB interface, the interface card HO730 includes an Ethernet interface. Configure the settings in the oscilloscope for all necessary parameters after you select ETHERNET as interface and press the soft menu key PARAMETER. You can specify all parameters and assign a fixed IP address. You can also assign a dynamic IP address with the activated DHCP function. Please contact your IT management to con-figure the settings properly.

If DHCP is used and the system cannot assign an IP address to the HMO (for instance, if no Ethernet cable is connected or the network does not support DHCP), it may take up to three minutes until a timeout allows the interface to be configured again.

If the device has an IP address, it can be accessed via web browser at this IP since the HO730 includes an integrated web server. Enter the IP address in the location bar on your browser (<http://xxx.xxx.xxx.xxx>). This opens a window that includes the device name and type, serial number and interfaces with technical information and configured parameters.




Fig. 13.1: web server with device data

To the left, you can use the link Screen Data to transfer a screenshot of the HMO (Right-click to copy to the clipboard for further use). The link SCPI Device Control opens a site with a console to send remote SCPI commands to the oscilloscope. For further information, consult the HO730 manual at www.hameg.com.

13.2 USB

All descriptions regarding the USB interface are true for the HO730 interface card as well as for the optional HO720 USB part. All currently available USB driver are fully tested, functional and released for Windows XP™ 32 Bit, Windows Vista™ or Windows 7™ both as 32Bit or 64Bit versions..

The USB interface must be chosen in the oscilloscope and does not need any setting. At the first connection Windows™ ask for a driver. The driver you can find on the delivered CD or in the internet at www.hameg.com at the download area for the HO720/HO730. The connection can be done via the normal USB or via the virtual COM port. The description how to install the driver you can find in the HO720/730 manual.

If the virtual COM port will be used, you must set USB as interface at the oscilloscope.

For further information, consult the HO720 manual at www.hameg.com.

13.3 RS-232 (option HO720)

The RS-232 interface is made as a 9 pole D-SUB connector. Over this bi directional interface you can transfer settings, data and screen dumps from an external device (PC) to the oscilloscope or vice versa. The direct physical link between oscilloscope and serial port of the PC can be done via an 9 pole cable with shielding (1:1 wired). The maximal length must below 3 m.

The exact pinning of the plug is as follows:

Pin

- 2 Tx Data (data from oscilloscope to external device)
- 3 Rx Data (data from external device to oscilloscope)
- 7 CTS ready for sending
- 8 RTS ready for receiving
- 5 ground (ground reference, due to oscilloscope
- category 0 - and power plug connected to earth)
- 9 +5 V supply voltage for external devices (max.400 mA)

The maximal amplitude at Tx, Rx, RTS und CTS is 12 Volt.

The standard RS-232 settings are:

8-N-2 (8 data bits, no parity, 2 stop bits),

RTS/CTS-Hardware-protocol: none.

In order to set these parameter at the HMO, please press the button SETUP at the front panel in the area GENERAL and hit the soft key INTERFACE at the opened soft menu. Make sure the RS-232 interface is chosen (blue backlighted) and then hit the button PARAMETER. This opens a menu where you can set and save all parameter for the RS-232 communication.

13.4 IEEE 488.2 / GPIB (Option HO740):

The optional interface card HO740 includes a IEEE488.2 interface. Configure the settings in the oscilloscope for all necessary parameters after you select IEEE488 as interface and press the soft menu key PARAMETER. For further information, consult the HO740 manual at www.hameg.com.

14 Technical Data

HMO3002 series 2-channel mixed signal oscilloscope
HMO3004 series 4-channel mixed signal oscilloscope
HMO3032, HMO3034: 300 MHz
HMO3042, HMO3044: 400 MHz
HMO3052, HMO3054: 500 MHz

from firmware version 5.405

Display

Display: 16.5cm (6.5") VGA Color Display

Resolution (L x W): 640 x 480 Pixel

Backlight: 500cd/m² (LED)

Display range in horizontal direction

without menu bar: 12 Div (600 Pixel)

with menu bar: 10 Div (500 Pixel)

Display range in vertical direction: 8 Div (400 Pixel)

with Virtual Screen usage: 20 Div

Color depth: 256 colors

Levels of brightness: 32

Trace display: pseudo-color, inverse intensity

Button brightness: light, dark

Vertical system

DSO mode

2-channel models: CH1, CH2

4-channel models: CH1, CH2, CH3, CH4

MSO mode

2-channel models: CH1, CH2, POD1, POD2

4-channel models: CH1, CH2, CH3|POD1, CH4|POD2

Analog channels

Y-bandwidth (-3dB)

(1mV, 2mV)/Div: HMO303x: 180MHz
HMO304x, HMO305x: 200MHz

(5mV bis 5V)/Div: HMO303x: 300MHz
HMO304x: 400MHz
HMO305x: 500MHz

Lower AC bandwidth: 2Hz

Bandwidth limitation: about 20MHz (switchable)

Rise time (computed)

HMO303x: < 1.166ns

HMO304x: < 0.875ns

HMO305x: < 0.700ns

DC gain accuracy: 2% of full scale

Input sensitivity

all analog channels: 1mV/Div to 5V/Div (1M Ω and 50 Ω)

coarse stepping: 12 calibrated steps, 1-2-5

variable stepping: freely between calibrated steps

Impedance: 1M Ω || 13pF $\pm$ 2pF (50 Ω switchable)

Coupling: DC, AC, GND

Max. input voltage: (derates at 20db/decade to 5V_{rms} above 100kHz)

1M Ω : 200V_p

50 Ω : 5V_{rms}, max. 30V_p

Position range: $\pm$ 8Div (from center of screen)

Offset control

1mV, 2mV: $\pm$ 0.2V - 8Div x sensitivity

5mV to 20mV:	$\pm$ 1.0V - 8Div x sensitivity
50mV:	$\pm$ 2.5V - 8Div x sensitivity
100mV, 200mV:	$\pm$ 20V - 8Div x sensitivity
500mV to 5V:	$\pm$ 50V - 8Div x sensitivity

XY/XYZ mode: selectively all analog channels

Inversion: selectively all analog channels

Logic channels with logic probe (HO3508/HO3516)

Thresholds: TTL, CMOS, ECL, user-defined (-2V to +8V)

Impedance: 100k Ω || 4pF

Coupling: DC

Max. input voltage: 40V_p

Triggering

Trigger mode

Auto: Triggers automatically also without any specific trigger event

Normal: Triggers only on specific trigger events

Single: Triggers once on a trigger event

Trigger indicator: Screen and panel (LED)

Trigger sensitivity:

up to 2mV/Div: 1.5Div

2mV/Div to 5mV/Div: 1.0Div

from 5mV/Div: 0.8Div

external: 0.5V_{pp} to 10V_{pp}

Trigger level setting

with auto level: Linking peak value and trigger level, adjustable between peak values of a signal

without auto level: $\pm$ 8Div (from center of screen)

external: $\pm$ 5V

Trigger coupling

Auto level: 5Hz to 300/400/500MHz

AC: 5Hz to 300/400/500MHz

DC: DC to 300/400/500MHz

HF: 30kHz to 300/400/500MHz

selectable filters

LF: DC to 5kHz, selectable in DC and auto level mode

low-pass (noise rejection): 200MHz, selectable in AC, DC, HF and auto level mode

Trigger hold-off: 50ns to 10s

External trigger input (BNC)

Impedance: 1M Ω || 14pF $\pm$ 2pF

Sensitivity: 0.5V_{pp} to 10V_{pp}

Trigger level: $\pm$ 5V

Max. input voltage: 100V_p

Coupling: DC, AC

Trigger/Auxiliary output (BNC)

Functions: Pulse output for every acquisition trigger event, error output on mask violation

Output level: 3.8V

Pulse polarity: positive

Pulse width: >150ns (trigger event), >0.5 μ s (mask violation)

Trigger types

Edge

Direction: increasing, decreasing, both

Trigger coupling: auto level AC, DC, HF

Switchable filters: LF, noise rejection

Sources: all analog and digital channels, mains, external (AC, DC)

Edge A/B	
Direction:	increasing, decreasing, both
Source A, B:	all analog channels, external (AC, DC)
Frequency range:	DC to 300/400/500 MHz
min. signal amplitude:	0.8 Div
Trigger level range: (separately adjustable with different sources)	±8 Div (from center of screen)
external:	±5.0 V
Trigger coupling	
State A:	auto level, AC, DC, HF, LF, low-pass
State B:	
same sources:	as state A
different sources:	DC, HF, low-pass
Trigger setting	
time based:	16 ns to 8.589 s, resolution min. 4 ns
event based:	1 to 2 ¹⁶ events
Pulse width	
Polarity:	positive, negative
Functions:	equal, not equal, lower, higher, within/without a range
Pulse duration:	4 ns to 8.5 s, resolution min. 0.5 ns
Sources:	all analog and digital channels
Logic	
Functions:	
Boolean operators:	AND, OR, TRUE, FALSE
time based operators:	equal, not equal, lower, higher, within/without a time range, timeout
Duration:	4 ns to 8.5 s, resolution min. 0.5 ns
States:	H, L, X
Sources:	all logic channels
Video	
Sync. pulse polarity:	positive, negative
supported standards:	NTSC, SECAM, PAL, PAL-M, SDTV 576i, HDTV 720p, HDTV 1080i, HDTV 1080p
Field:	even/odd, either
Line:	line number selectable, all
Sources:	all analog channels, external (AC, DC)
Risetime	
Functions:	rise/fall time, both
Time range:	4 ns to 8.5 s, resolution min. 0.5 ns
Time based operators:	equal, not equal, lower, higher
Variance:	±2 ns to ±33.5 ms, resolution 2 ns
Sources:	all analog channels
Runt	
Polarity:	positive, negative, both
Duration:	n/a
Sources:	all analog channels
Serial Busses (H0010/11/12 option)	
Bus representation:	Up to two busses can be analyzed at the same time. Color-coded display of decoded data in ASCII, binary, decimal and hexadecimal format.
Option H0010:	Analysis of I ² C, SPI, UART/RS-232 signals on analog and logic channels
Option H0011:	Analysis of I ² C, SPI, UART/RS-232 signals on all analog channels
Option H0012:	Analysis of CAN and LIN signals on analog and logic channels

Trigger types by protocols	
I ² C:	Start, Stop, ACK, NACK, Address/Data
SPI:	Start, End, Serial Pattern (32 Bit)
UART/RS-232:	Startbit, Frame Start, Symbol, Pattern
LIN:	Frame Start, Wake Up, Identifier, Data, Error
CAN:	Frame Start, Frame End, Identifier, Data, Error
Horizontal system	
Display	
Time domain (Yt):	main screen, time domain and zoom window
Frequency domain (FFT):	time domain and frequency domain window (FFT)
XY/XYZ mode:	Voltage (XY), Intensity (Z)
VirtualScreen:	virtual display of 20 Div for all math, logic, bus, reference signals
Reference signals:	up to 4 references
Channel deskew:	-62.5 ns to +61.5 ns, step size 500 ps
Memory zoom:	up to 250,000:1
Time basis	
Accuracy:	15.0 × 10 ⁻⁶
Aging:	±5.0 × 10 ⁻⁶ per year
Operation modes	
REFRESH:	1 ns/Div to 50 s/Div
ROLL:	50 ms/Div to 50 s/Div
Acquisition system	
Realtime sampling rate	
2-channel models:	2 × 2 GSa/s or 1 × 4 GSa/s
4-channel models:	4 × 2 GSa/s or 2 × 4 GSa/s
Logic channels:	16 × 1 GSa/s
Memory depth	
2-channel models:	2 × 4 MPts or 1 × 8 MPts
4-channel models:	4 × 4 MPts or 2 × 8 MPts
Resolution:	8 Bit, (HiRes up to 10 Bit)
Waveform arithmetics:	refresh, roll (loose/triggered), average (up to 1024), envelope, peak detect (500 ps), filter (low-pass, adjustable), high resolution (up to 10 Bit)
Record modes:	automatic, max. sampling rate, max. waveform update rate, specific record length (10 kPts to 2 MPts)
Interpolation	
all analog channels:	sin(x)/x, linear, sample-hold
logic channels:	pulse
Delay	
pre-trigger:	0 to 4 × 10 ⁶ Sa × (1/sample rate), x2 in interlaced mode
post-trigger:	0 to 8,59 × 10 ⁹ Sa × (1/sample rate)
Waveform update rate:	up to 5000 Wfm/s
Waveform display:	dots, vectors, persistence afterglow
Persistence afterglow:	min. 50 ms
Segmented Memory (H0014 option)	
Segment size:	5 kPts to 2 MPts
max. number of segments:	up to 1,000
re-arming time:	less than 3 μs
sampling rate:	200.000 Wfm/s
Segment player:	Displays all recorded segments manually or automatically. All measurement functions including pass/fail testing can be applied on the recorded segments.

Waveform Measurements	
Operation:	menu-driven (multilingual), auto-set, help functions (multilingual)
Automatic measurements:	Voltage (V_{pp} , V_{p+} , V_{p-} , V_{rms} , V_{avg} , V_{min} , V_{max}), amplitude, phase, frequency, period, rise/fall time (80%, 90%), overshoot (pos/neg), pulse width (pos/neg), burst width, duty cycle (pos/neg), standard deviation, delay, crest factor, edge/pulse count (pos/neg), trigger period, trigger frequency
Automatic search functions:	Edge, pulse, peak, rise/fall time, runt
Cursor measurements:	Voltage (V_1 , V_2 , ΔV), time (t_1 , t_2 , Δt , $1/\Delta t$), ratio X, ratio Y, pulse and edge count (pos/neg), peak values (V_{pp} , V_{p+} , V_{p-}), mean/RMS/standard deviation, duty cycle (pos/neg), burst width, rise/fall time (80%, 90%), ratio marker, crest factor
Quick measurements: (QUICKVIEW)	Voltage (V_{pp} , V_{p+} , V_{p-} , V_{rms}), frequency, period (predefined), 6 additional measurement functions (see automatic measurement functions) freely selectable plus statistics
Marker:	up to 8 freely positionable markers for easy navigation, automatic marker positioning based on search specification
Frequency counter (hardware based)	
Resolution:	7 digit
Frequency range:	0.5 Hz to 300/400/500 MHz
Accuracy:	15.0×10^{-6}
Aging:	$\pm 5.0 \times 10^{-6}$ per year
Mask Testing	
Functions:	Pass/Fail comparison with an user-defined mask performed on waveforms
Sources:	all analog channels
Mask definition:	Mask enclosing acquired waveform with user-defined tolerance
Actions	
on mask violations:	beep, acquisition stop, screenshot, trigger pulse, automatically saving trace data
during acquisition:	Statistics: number of completed tests, number of passes / failed acquisition (absolute and in percent), test duration
Waveform Maths	
Quickmath	
Functions:	addition, subtraction, multiplication, division
Sources:	2 analog channels
Mathematics	
Functions:	addition, subtraction, multiplication, division, minimum / maximum, square, square root, absolute value, pos/neg wave, reciprocal, inverse, $\log_{10}/\ln$, derivation, integration, filter (lowpass/highpass)
Editing:	formula editor, menu-driven
Sources:	all analog channels, user-defined constants
Storage location:	Math. Memory
Number of formula sets:	5 formula sets
Number of equations:	5 equations per formula set
Simultaneous display of math. Functions:	1 formula set with max. 4 equations
Frequency Analysis (FFT)	
Parameters:	frequency span, center frequency, vertical scale, vertical position
FFT length:	2 kpts, 4 kpts, 8 kpts, 16 kpts, 32 kpts, to 64 kpts

Window:	Hanning, Hamming, Rectangular, Blackman
Scale:	dBm, dBV, V_{rms}
Waveform arithmetics:	refresh, envelope, average (up to 512)
Cursor measurement:	2 horizontal cursors, previous/next peak search
Sources:	all analog channels
Pattern Generator	
Functions:	probe adjust, bus signal source, counter, random pattern
Probe ADJ output:	1 kHz, 1 MHz square wave: $1.0V_{pp}$ ($t_r < 4\text{ ns}$)
Bus Signal Source (4 Bit):	I ² C (100 kBit/s, 400 kBit/s, 1 MBit/s), SPI (100 kBit/s, 250 kBit/s, 1 MBit/s), UART (9600 Bit/s, 115,2 kBit/s, 1 MBit/s)
Counter (4 Bit):	frequency: 1 kHz, 1 MHz direction: incrementing
Random pattern (4 Bit):	frequency: 1 kHz, 1 MHz
Interfaces	
Connectors and ports	
for mass storage:	2 x USB-Host, Typ A (FAT16/32)
for remote control:	HO730 dual interface: Ethernet (RJ-45) / USB-Device (Typ B)
optional interfaces:	HO720 dual interface: USB-Device (Typ B) / RS-232 HO740 interface: IEEE-488 (GPIB)
external monitor interface:	DVI-D (480 p, 60 Hz), HDMI compatible
General Data	
Application memory:	8 MB for references, formulas, device settings, languages and help functions
Save/Recall	
Device settings:	on internal file system or external USB memory, available file formats: SCP, HDS
Reference waveforms:	on internal file system or external USB memory, available file formats: BIN (MSB/LSB), FLT (MSB/LSB), CSV, TXT, HRT
Traces:	on external USB memory, available file formats: BIN (MSB/LSB), FLT (MSB/LSB), CSV, TXT, HRT
Data:	display or acquisition data
Sources:	single or all analog channels
Screenshots:	on external USB memory, available file formats: BMP, GIF, PNG
Math. equation sets:	on internal file system or external USB memory
Realtime Clock (RTC):	date and time
Power supply	
AC supply:	100 V to 240 V, 50 Hz to 60 Hz, CAT-II
Power consumption	
2-channel models:	max. 70 W
4-channel models:	max. 90 W
Safety:	in line with IEC 61010-1 (ed. 3), IEC 61010-2-30 (ed. 1), EN 61010-1, EN 61010-2-030, CAN/CSA-C22.2 No. 61010-1-12, CAN/CSA-C22.2 No. 61010-2-030-12, UL Std. No. 61010-1 (3rd Edition), UL 61010-2-030
Temperature	
Operating temperature range:	+5°C to +40°C
storage temperature range:	-20°C to +70°C
rel. humidity:	5% to 80% (without condensation)

Mechanical data	
Dimensions (W x H x D):	285 x 175 x 220 mm
Weight:	3.6 kg
All specifications at 23°C after 30 minute warm-up.	

Bandwidth Upgrade Vouchers

Description	Voucher-Codes
Bandwidth upgrade 300 MHz to 400 MHz	HV342 (2-channel models) HV344 (4-channel models)
Bandwidth upgrade 300 MHz to 500 MHz	HV352 (2-channel models) HV354 (4-channel models)
Bandwidth upgrade 400 MHz to 500 MHz	HV452 (2-channel models) HV454 (4-channel models)

Bus Analysis and Segmented Memory

Description	Option-Code	Voucher-Code
I ² C, SPI, UART/RS-232 on analog and digital channels	HOO10	HV110
I ² C, SPI, UART/RS-232 on all analog channels	HOO11	HV111
CAN und LIN on analog and digital channels	HOO12	HV112
Segmented memory	HOO14	HV114

Accessories included:

HO730 Ethernet/USB dual-interface card, Line cord, printed operating manual, 2/4 probes (amount=number of channels), 10:1 with attenuation ID (HZ350 400/300 MHz, HZ355 500 MHz), software-CD

Recommended accessories:

HOO10	Serial bus trigger and hardware accelerated decode, I ² C, SPI, UART/RS-232 on Analog channels and Logic channel
HOO11	Serial bus trigger and hardware accelerated decode, I ² C, SPI, UART/RS-232 on Analog channels
HOO12	Serial bus trigger and hardware accelerated decode, CAN, LIN on Logic channels and Analog channels
HO3508	Active 8 Channel Logic Probe
HO3516	2 x HO3508, active 8 Channel Logic Probes
HO720	Dual-Interface USB-Device/RS-232
HO740	Interface IEEE-488 (GPIB), galvanically isolated
HZ46	4RU 19" Rackmount Kit
HZ99	Carrying Case for protection and transport
HZ355	Slimline Probe 10:1 with automatic identification
HZ355DU	Upgrade from 2 x HZ350 to 2 x HZ355
HZO20	High voltage probe 1000:1 (400 MHz, 1000 Vrms)
HZO30	Active probe 1 GHz (0.9 pF, 1 MΩ, including many accessories)
HZO40	Active differential Probe 200 MHz (10:1, 3.5 pF, 1 MΩ)
HZO41	Active differential Probe 800 MHz (10:1, 1 pF, 200 kΩ)
HZO50	AC/DC Current probe 30 A, DC...100 kHz
HZO51	AC/DC Current probe 100/1000 A, DC...20 kHz

15 Appendix

15.1 List of figures

Fig. 1.1:	Various positions for HMO instruments	4
Fig. 1.2:	Product labeling in accordance with EN 50419	7
Fig. 2.1:	Frontview of the HMO3004	8
Fig. 2.2:	Section A of the control panel	8
Fig. 2.3:	Section B, C and D of the control panel	9
Fig. 2.4:	Screen view	9
Fig. 2.5:	Rear panel HMO3004 series	9
Fig. 2.6:	Selection of basic soft menu elements	10
Fig. 2.7:	Basic soft menu elements for settings and navigation	10
Fig. 2.8:	Menu for basic settings	11
Fig. 2.9:	Updating menu and information window	11
Fig. 2.10:	Menu and information window for help updates	12
Fig. 2.11:	„UPGRADE“ menu	12
Fig. 2.12:	Manual licence key input	13
Fig. 2.13:	Successful self alignment	13
Fig. 2.14:	Logic probe self alignment (refer to page 14)	13
Fig. 3.1:	Section A of the control panel	14
Fig. 3.2:	Screen display after connection of the probe	14
Fig. 3.3:	Screen display after changing to DC coupling	15
Fig. 3.4:	Screen display after Autosetup	15
Fig. 3.5:	Section D of the control panel with zoom key	15
Fig. 3.6:	Zoom function	15
Fig. 3.7:	Cursor measurements	15
Fig. 3.8:	Quickview parameter measurement	16
Fig. 3.9:	AutoMeasure menu	16
Fig. 3.10:	Selection of parameter	16
Fig. 3.11:	Measuring the parameters of two sources	17
Fig. 3.12:	Formula editor	17
Fig. 3.13:	Save/Recall menu	17
Fig. 3.14:	SCREENSHOTS menu	17
Fig. 3.15:	File naming	18
Fig. 4.1:	Control panel for the vertical system	18
Fig. 4.2:	Short menu for vertical settings	18
Fig. 4.3:	Correct connection of the probe to the probe adjust output	19
Fig. 4.4:	Vertical offset	19
Fig. 4.5:	Threshold setting	20
Fig. 4.6:	Name selection	20
Fig. 5.1:	Control panel of the horizontal system	21
Fig. 5.2:	AM modulated signal with maximum repeat rate	22
Fig. 5.3:	AM modulated signal with maximum sampling rate	23
Fig. 5.4:	AM modulated signal with automatic setting	23
Fig. 5.5:	Zoom function	24
Fig. 5.6:	Marker in zoom mode	25
Fig. 5.7:	Search mode with event list	26
Fig. 6.1:	Control panel for the trigger system	26
Fig. 6.2:	Coupling modes with slope trigger	27
Fig. 6.3:	Menu for pulse trigger settings	28
Fig. 6.4:	Menu for logic trigger settings	28
Fig. 6.5:	Logic channels' settings display	29

Fig. 6.6:	Video trigger menu	29
Fig. 7.1:	Drawing of the virtual screen area and an example	31
Fig. 7.2:	Menu for setting the signal display intensities	31
Fig. 7.3:	Persistence function.	31
Fig. 7.4:	Settings in the X–Y menu	32
Fig. 7.5:	Settings for the Z input	32
Fig. 8.1:	Selection menu for cursor measurements	33
Fig. 8.2:	Menu for the automatic measurements settings.	34
Fig. 8.3:	Statistics for automatic measurements.	36
Fig. 9.1:	Mathematics short menu	37
Fig. 9.2:	Quick Mathematics menu	37
Fig. 9.3:	Formula editor for formula sets	37
Fig. 9.4:	Entry of constants and units	38
Fig. 9.5:	FFT illustration	39
Fig. 9.6:	Advanced FFT menu	40
Fig. 9.7:	PASS/FAIL mask test.	41
Fig. 10.1:	Basic menu for instrument settings	42
Fig. 10.2:	Storing instrument settings	42
Fig. 10.3:	Loading instrument settings	42
Fig. 10.4:	Import/Export menu for instrument settings	43
Fig. 10.5:	Loading and storing references.	43
Fig. 10.6:	Storage menu for curves	44
Fig. 10.7:	Screenshot menu.	44
Fig. 10.8:	Definition of FILE/PRINT key	45
Fig. 11.1:	Settings for the logic channel display	46
Fig. 12.1:	Menu for the definition of buses	49
Fig. 12.2:	Decoding format selection menu	49
Fig. 12.3:	Example I ² C BUS with BUS table	49
Fig. 12.4:	I ² C BUS signal source	50
Fig. 12.5:	I ² C 7 bit address.	50
Fig. 12.6:	Menu for the definition of I ² C sources	50
Fig. 12.7:	I ² C message decoded with hexadecimal values	51
Fig. 12.8:	I ² C READ/WRITE trigger menu	51
Fig. 12.9:	I ² C data trigger menu	51
Fig. 12.10:	Example I ² C BUS with BUS table	51
Fig. 12.11:	SPI BUS signal source	52
Fig. 12.12:	Simple configuration of a SPI BUS	52
Fig. 12.13:	Menu for the definition of a SPI BUS	53
Fig. 12.14:	SPI trigger menu	53
Fig. 12.15:	SPI data trigger menu	54
Fig. 12.16:	UART bit sequence	54
Fig. 12.17:	Page 1 of the menu to define a UART BUS	54
Fig. 12.18:	Page 2 2 UART BUS setup menu	54
Fig. 12.19:	Trigger menu UART data	55
Fig. 12.20:	UART trigger menu page 2	55
Fig. 12.21:	Setting the SAMPLE POINT during the CAN con- figuration	56
Fig. 12.22:	CAN data trigger menu	56
Fig. 12.23:	Layout LIN byte structure	57
Fig. 12.24:	Menu for the definition of a LIN BUS	57
Fig. 12.25:	LIN data trigger menu	58
Fig. 13.1:	web server with device data	59

15.2 Glossary

A

acquisition memory: 22, 23, 24, 44
 acquisition mode: 9, 21, 24, 31
 amplitude: 16, 25, 32, 34, 35, 36, 39, 40, 41, 44, 59, 61, 62
 analog channel: 19, 25, 46, 55
 automatic measurements: 16, 17, 33, 34, 36, 40, 47
 auto mode: 26

B

Blackman window function: 40
 BNC connector: 10, 15
 BUS configuration: 50
 BUS configuration: 48, 50, 52, 53, 54, 55, 56, 57
 BUS signal source: 8, 11, 12, 41, 62

C

CAN BUS: 55, 56
 coupling: 2, 15, 18, 19, 27, 60, 61
 cursor measurements: 10, 15, 16, 33, 34, 47
 CVBS signal: 29

D

DC offset: 19
 duty cycle: 16, 62

E

envelope: 21, 39, 61, 62
 external trigger: 8, 10, 26, 27, 52

F

file manager: 10, 13, 39, 42, 43
 file name: 18, 43
 formula editor: 17, 37, 38, 62
 frequency: 2, 12, 16, 19, 21, 23, 27, 32, 33, 35, 36, 39, 40, 47, 61, 62
 frequency analysis: 37, 39

G

grid intensity: 31

H

Hamming window function: 40
 Hanning window function: 40
 hardware counter: 33, 36
 help: 11, 12, 45, 62
 High Pass Filter: 38
 hold off time: 29

I

I²C BUS: 49, 50
 input impedance: 6, 18
 Instrument settings: 17, 42
 interface: 2, 8, 9, 10, 11, 23, 45, 58, 59, 62
 interlace mode: 24
 interpolation: 22

L

language: 9, 11, 12, 45

licence key: 12, 13, 48

LIN BUS: 57

logic channel: 28, 46, 47, 50

logic pod: 22, 24

logic probe: 8, 10, 14, 26, 28, 46, 48, 60

logic trigger: 20, 28, 46, 49

Low Pass Filter: 38

M

marker function: 21, 25

mask test: 8, 40, 41

mathematical functions: 17, 37, 38

mathematical graph: 17

mixed-signal operation: 10

N

navigation function: 25

P

part detection: 19

peak detection: 22, 23

peak voltage: 16, 19, 40

period: 4, 5, 16, 22, 25, 31, 33, 34, 35, 36, 40, 55, 62

persistence function: 31, 32

polarity: 30, 55, 60, 61

pulse trigger: 27, 28, 29

pulse width: 16, 25, 26, 27, 28, 29, 35, 40, 62

Q

Quick Mathematics: 37

Quick View: 8, 16, 40

R

reference: 8, 9, 11, 21, 25, 28, 29, 33, 34, 35, 36, 42, 43, 44, 57, 59, 61, 62

reference curves: 42, 43, 44

reference menu: 44

references signals: 31

reference time: 28, 29

Repair: 5

rise/fall time: 25, 61, 62

runt: 25, 26, 62

S

sampling rate: 9, 21, 22, 23, 24, 43, 44, 48, 61

Screen displays: 17

screenshot: 18, 44, 45, 58, 62

search function: 25

select option: 26

self alignment: 13, 14

sensitivity: 15, 18, 19, 60

serial BUS analysis: 12, 20, 48

shunt: 20

Signal inversion: 19

slope: 9, 25, 26, 27, 28, 34, 35, 36, 49, 50, 51, 52, 55

slope trigger: 25, 27, 63

source curve: 41

SPI BUS: 51, 52

square wave: 15, 35, 40, 62

T

threshold: 20, 29, 32, 33

time base: 9, 13, 15, 16, 21, 22, 23, 24, 25, 26, 29, 32, 39, 42, 43

trigger condition: 26, 27, 28, 31, 42, 51, 53, 54, 55, 56, 57

trigger level: 9, 25, 27, 28, 60

trigger mode: 29

trigger signal: 9, 27, 36

trigger sources: 26

trigger system: 26, 29

trigger time position: 21

trigger type: 9, 26, 27, 28, 30, 31, 54

U

UART BUS: 53, 54

USB connector: 17, 18

USB port: 8, 12, 13

USB stick: 12, 13, 17, 18, 37, 38, 39, 41, 42, 43, 44, 48, 49

V

video trigger: 29

V marker: 15, 16, 34

voltage level: 35

W

Warranty: 5

X


XY display: 32

Z

Z input: 32

zoom function: 24

zoom window: 24, 61



value-instruments.com

www.hameg.com

HAMEG Instruments GmbH
Industriestr. 6 | 63533 Mainhausen | Germany | Tel +49 (0) 6182 8000

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG
HAMEG Instruments® is a registered trademark of HAMEG Instruments GmbH; Trade names are trademarks of the owners
07/2014 | © HAMEG Instruments GmbH | 41-3000-00E0
Subject to change without notice